
DECORA

habitat ®



Spare Parts



www.argos-support.co.uk



■ Help@ClickSpares.co.uk



0370 112 1928

Customer Support



0345 640 2020



Product Details

DECORA GLASS COFFEE TABLE 1951653

IMPORTANT, RETAIN FORFUTURE REFERENCE: READ CAREFULLY.

- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- This product has been constructed to be used in the domestic environment only and not for commercial purposes.

- Assemble the item as close to its final position(in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.



•We do not recommend the use of power drill/drivers for inserting screws

as this could damage the unit.
Only use hand screwdrivers.

- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.


Care and maintenance


- Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.
- Use a dry cloth to clean the product, furniture polish is not recommended.
- From time to time check that there are no loose screws, nuts or bolts.
 If there are please re-tighten.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Additional Guidance

- Maximum loading weight 30kg
- This product is compliant EN12521.

Fittings (Shown to scale)





① glass table x1 (80*50*38cm)

