




EN SMARTLITE® QUARTZ ALARM OPERATING INSTRUCTIONS

Thank you for your purchase of this quality clock. Please read these instructions carefully and keep in a safe place for future reference.



1. Time set knob.
2. Alarm set knob.
3. Snooze/light button.
4. Alarm on/off switch.
5. Battery compartment.
6. Smartlite® dimmer wheel.

SMARTLITE® FEATURE

Smartlite® is an innovative technology that automatically illuminates the display for easy night time viewing. To prolong battery life the Smartlite® sensor will automatically turn the feature off in the bright environment.

ACTIVATING THE CLOCK

Insert 3 X AA battery into the battery compartment, taking care to observe the polarity.

SETTING THE TIME

Rotate the TIME SET knob in the direction of the arrow until the correct time is reached.

SETTING THE ALARM

Rotate the ALARM SET knob in the direction of the arrow to the desired alarm time.

TO TURN ON/OFF THE ALARM

Slide the ALARM ON/OFF switch to ON or OFF.

USING THE SNOOZE FEATURE

When the alarm sounds, press the SNOOZE/LIGHT button to snooze the alarm for approximately 5 minutes.

TO LIGHT THE DIAL

Press the SNOOZE/LIGHT button to activate the light.

CHANGING THE BATTERY

It is recommended that you replace the battery annually even if the product is still running. Only use 3 X AA (1.5V) Alkaline batteries in this clock. Remove the battery if the clock is stored or not in use. Remove exhausted battery from the product.

Warning: Do not recharge non-rechargeable batteries.

Please dispose of used battery in a responsible manner. For more information please contact your local authority.

MAINTENANCE

A soft cloth may be used to clean your clock. Do not use any corrosive cleaner or chemical solutions on the clock. Keep the clock clean and dry to avoid any problems.

YOUR GUARANTEE

Your clock is guaranteed for 2 years from the date of purchase against any faults arising from defective materials or manufacture. Damage caused through careless handling, misuse or in transit is expressly excluded. Should this clock fail within 2 years please return it to your retailer.

Environmental Protection

Disposal of electrical & electronic equipment



Do not dispose of this product with household waste. For the proper treatment, recovery and recycling please take this product to the appropriate collection point. If you are unsure of where this is contact your local authority. Improper disposal may be harmful to the environment.

