



AS SEEN ON
high street tv

NEW XHOSE 8 SPRAY NOZZLE

EASILY CONNECT TO YOUR XHOSE OR ANY GARDEN HOSE **TURN THE NOZZLE TO SELECT THE MODE**
8 MODES - MIST, SHOWER, ANGLE, CENTRE, FLAT, CONE, SOAKER, FULL



WWW.OFFICIALXHOSE.CO.UK




AS SEEN ON
high street tv

NEW XHOSE 8 SPRAY NOZZLE

**CONNECTS TO YOUR XHOSE
OR ORDINARY GARDEN HOSE**

**HOW TO CONNECT THE SPRAY NOZZLE:
PUSH THE SPRAY NOZZLE INTO YOUR XHOSE
OR ANY GARDEN HOSE**

**SELECT THE SPRAY MODE:
THE 8 WAY SPRAY NOZZLE ALLOWS YOU TO
SELECT THE SETTING OF YOUR CHOICE
SIMPLY TURN THE DIAL TO DESIRED MODE**



PLEASE RETAIN THIS INFORMATION
FOR FURTHER USE



5 060187 925744

MADE IN
CHINA

Distributed by:
High Street TV, PO Box 724,
Altrincham, WA15 5BJ

high street tv

www.highstreettv.com

WWW.OFFICIALXHOSE.CO.UK