

CASIO®

F-91W-1XY

Specifications

- ⇒ 50M WR
- ⇒ Daily Alarm
- ⇒ Stopwatch
- ⇒ LED Light



Model variations may differ in appearance from the example above.

Stop Watch	1/100-sec accuracy	<p>Press C until display shows stopwatch function (ST) Start and stop the stop watch using button A.</p> <p>Use following to measure times with the Stopwatch.</p> <p>(a) Time loss Start → Stop → Re-start → Stop → Reset</p> <p>(b) Split time measurement Start → Split → Split release → Stop → Reset</p> <p>(c) 1st-2nd place times Start → Split (The first runner finishes.) → Stop (The second runner finishes. Record the time of the first runner.) → Split release (Record the time of the second runner.) → Reset</p>
Alarm	Allows you to specify the hour, minutes, day and month of the alarm.	In Alarm Mode, Press L , to set the hour, the digits change with every push of Button A . To set the minutes Press L , and advance the digits with Button A . Press L to complete the alarm settings. If button C is pressed the watch reverts to the regular time keeping mode at any stage. Of alarm setting.
Water Resistant	Suitable for bathing, swimming, and showering. not for diving.	Not suitable for swimming, snorkelling or diving. *Do not fully submerge for long periods of time.
LED Light	In any mode Press L to illuminate display	