

### CASIO®

#### F-91W-1XY

#### Specifications

- ⇒ 50M WR
- ⇒ Daily Alarm
- ⇒ Stopwatch
- ⇒ LED Light



Model variations may differ in appearance from the example above.

<b>Stop Watch</b>	1/100-sec accuracy	<p>Press <b>C</b> until display shows stopwatch function (ST) Start and stop the stop watch using button <b>A</b>.</p> <p>Use following to measure times with the Stopwatch.</p> <p>(a) Start → Time loss → Stop → Re-start → Stop → Reset</p> <p>(b) Split time measurement: Start → Split → Split release → Stop → Reset</p> <p>(c) 1st-2nd place times: Start → Split (The first runner finishes.) → Stop (The second runner finishes. Record the time of the first runner.) → Split release (Record the time of the second runner.) → Reset</p>
<b>Alarm</b>	Allows you to specify the hour, minutes, day and month of the alarm.	In Alarm Mode, Press <b>L</b> , to set the hour, the digits change with every push of <b>Button A</b> . To the set the minutes Press <b>L</b> , and advance the digits with <b>Button A</b> . Press <b>L</b> to complete the alarm settings. If <b>button C</b> is pressed the watch reverts to the regular time keeping mode at any stage. Of alarm setting.
<b>Water Resistant</b>	Suitable for bathing, swimming, and showering. not for diving.	Not suitable for swimming, snorkelling or diving. *Do not fully submerge for long periods of time.
<b>LED Light</b>	In any mode Press <b>L</b> to illuminate display	