
Daisy Sleigh White Frame

Assembly Instructions - Please keep for future reference

258/3312



Dimensions

Width - 96cm Depth - 216cm Height - 99.5cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: Argos = 0345 640 0800**

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

IMPORTANT! KEEP FOR FUTURE REFERENCE

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.



• To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- Improper use of electrical tools will crack the components.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Warnings

- Regularly check and ensure that all bolts and fittings are tightened properly.
- The recommended mattress size is L1900 x W900 mm.
- This product should only be used on firm, level ground.
- Make sure the legs remain in contact with the ground.
- This product is intended for children in the age of 4 to 13 years old.

- Not suitable for children under 4 years.
- Prohibit your children from bouncing and jumping on the bed.
- Do not place this child's bed near heat sources, windows (blind cords, curtain pulls or other strings or cords) and other furniture.
- Place the bed tight to any wall or have a gap of 300mm between the wall and the side of the bed.
- Do not use this child's bed if any part is broken, torn or missing.
- THIS BED COMPLIES WITH BS8509:2008+A1:2011
- Retailer: Argos Ltd. MK9 2NW

Handy Hints


 Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
Regular ensure th fittings ar properly.

• Regularly check and ensure that all bolts and fittings are tightend properly. *Note:* if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: Argos = 0345 640 0800**

Please check you have all the panels listed below




Components - Key Diagram




Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are correct amount to complete the assembly. In some cases more fittings may be supplied than are required.





Step 4

Mounting the footboard legs to the footboard.

Place the barrel nuts ① onto the holes indicated on the footboard 2 and using screws ③ and screws ④ to fix the left footboard leg ⑤ and the right footboard leg ⑥ onto the footboard 2, using allen key ① to tighten it.


Note the holes of barrel nuts pointing towards to the screws.

Step 5

Mounting the screws to the headboard legs and the footboard legs.

Mounting the screws (A) into the holes indicated on the headboard legs (3) and (4) and the footboard legs (5) and (6), using the allen key (1).

Note: Please make sure the length of screw (A) after tightening to the leg should remain 47 - 49 mm and the screw head is up as shown diagram.



Step 6 1 Headboard Assembly the 3 headboard legs and the Left headboard leg footboard legs to the sides. 7 Fit the headboard legs 3, 2 4 and the footboard Side Footboard legs 5, 6 into the holes indicated on the sides 7. Place the washers **B** onto the holes indicated on the sides 7. Using nuts **C** and 7 4 spanner **J** to fix the Side Right headboard leg 6 headboard and footboard Right footboard leg to the sides 7. 5 Left footboard leg Again please note the holes of nuts pointing 7 towards to the screws. 0 **J**]]]]]]]] Ô 7 0 Ô 0 7

Step 7


Additional step to fix the slats.

Note: The slats are supplied separately.

Spreading the slats evenly onto the bed frame.

Fix the slats to the slatholders using screws

Watch out! The screws attach the slatholders to the sides never collide to the screws that fix the slats to the slatholders.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline:** Argos = 0345 640 0800

Dear Customer.

Please note that the product you have purchased is a natural living timber.

Just like nature itself, wood varies in shape and colour. Knots, vein patterns, resin pockets and colour differences contribute to giving the piece of furniture its beauty and form - a natural part of solid wood.

Although the tree has been cut down and dried, it is still alive and therefore will react to high and low temperatures, light, humidity, drought and time.

In cold and dry periods, the wood contracts which may lead to small cracks in the piece of furniture. The reverse happens in warm and humid periods where the wood expands and this may result in slight unevenness.

The colour of the wood also changes with time, particularly if the furniture is place in a light place. This is a natural process and part of owning a piece of furniture made of solid wood.

Any flexing that has occurred during transport will re-correct it self once this product is correctly assembled.

Tighten all joints of the furniture after six months.

Please keep these instructions in a safe place for future use.