







Disney




43212











































































































Disney
PRINCESS

4+

43211



©Disney

[LEGO.com/disney](https://www.lego.com/disney)



Rebuild
the
world™





LEGO and the LEGO logo are trademarks of the LEGO Group. ©2023 The LEGO Group. 6461319
©Disney