



SPIRIT

AP062



FEATURES

1. Time display
2. Alarm and snooze at 5 minute intervals
3. 7 colors changing LED lights
4. Backlight for 15 seconds
5. Power supply: 5V/1.2A adaptor or USB cable
6. Requires three “AA” batteries (not included)

BUTTONS FUNCTION

SET UP, DOWN, LIGHT and TOUCH button

SET BUTTON

1. In time display mode, long press to enter the time setting in the sequence: 12/24hr setting-hour setting - minute setting - AL hour setting - AL minute setting - quit.
2. In 7-color-LED changing mode, press the LIGHT button to switch the LED light.

UP BUTTON

1. In setting mode, press the UP button to increase 1 step, press and hold the UP button to increase quickly.
2. In LED color changing mode, press the UP button to increase 10% brightness, press and hold the UP button to keep the brightness increasing.

DOWN BUTTON

1. In normal time display mode, press the DOWN button to turn on/off the alarm.
2. In setting mode, press the DOWN button to decrease 1 step, press and hold it to decrease quickly.
3. In LED changing mode, press the DOWN button to decrease 10% brightness, press and hold the DOWN button to keep brightness decreasing.

TOUCH BUTTON

1. In any mode, press the TOUCH button to turn on/off the LED lights.
2. When the alarm is sounding, press TOUCH button to enter snooze with an interval of 5 minutes.

BACKLIGHT

1. Touch the light button to turn on backlight (on for 15 seconds).

TIME AND ALARM SETTING

1. In time display mode, press and hold the SET button to enter time setting in sequence: 12/24hr setting - hour setting - minute setting - AL hour setting - AL minute setting - alarm sound selection - quit.
2. Press the UP button to go ahead 1 step, press and hold for 2 seconds to go ahead at an 8 steps/second speed.
3. Press the DOWN button to go back 1 step, press and hold for 2 seconds to go back at an 8 steps/second speed.
4. Press SET to confirm the setting.
5. Without any operation in 15 seconds, quit the setting mode and the setting values are saved.

ALARM FORMAT

1. In time display mode, press the DOWN button to turn on/off the alarm in sequence: AL on - AL off.
2. Under alarm mode and with alarm time display for 3 seconds, it goes back to normal time display, press the DOWN button to turn off the alarm.
3. 30 minutes before the alarm time, the LED lights will appear gradually, when the alarm time is up, the LED lights are fully on with sound "BI, BI, BI, BI", if without any operation, the sound will work for 5 minutes and then will turn off.
4. During alarming, press the TOUCH button to turn on the snooze, the snooze symbol appears on the LED and the second dots will flicker, the LED lights are on with lowest brightness level, press any other button to exit.
5. Under snooze mode, press the TOUCH button to turn on the LED lights, press any other button to exit and the LED lights will show on the lowest brightness.

BACKLIGHT FUNCTION

1. When powered by batteries, press the UP button to turn on the backlight for 15 seconds.
2. When powered by the adaptor, the backlight will be on all the time.

LED LIGHTS

1. In any mode, touch the TOUCH button to turn on/off the LED lights.
2. The default LED light is in warm white color, 50% brightness, after that it will keep the last records when it quits, e.g., it's blue LED light and full brightness, if it is turned off and then turned back on again, it will stay to a blue LED light with full brightness.
3. When the LED lights are on, press the LIGHT button to switch the LED light colors in the sequence: warm white - circular display: red - yellow - green - light blue - blue - purple.
4. When it's under circular LED display, each LED color will remain on 4 seconds.
5. The color changing will show in a gradual change.
6. In LED color changing mode, press the UP button to increase 10% brightness, press and hold the UP button to keep brightness increasing.
7. In LED colour changing mode, press the DOWN button to decrease 10% brightness, press and hold the DOWN button to keep brightness decreasing.

GUARANTEE

Your timepiece is guaranteed against any defective parts or construction for 2 years from the date of purchase.

Your guarantee is only valid if you present your original receipt when returning the item.

The guarantee provides you with the rights which are in addition to the consumer statutory rights and therefore, do not limit the effect of these statutory rights.

Please note that this guarantee does not cover breakages caused by accident or maltreatment. Batteries are not covered.

All products should be returned to:

PH Services, Precision House, Unit 4, Starley Way, Solihull, B377GN

WEEE

The wheellie bin symbol indicates that waste and electrical equipment should not be treated as normal household waste. It should be segregated and recycled when it has reached the end of its life, which can be done free of charge at civic amenity sites.

For your nearest facilities see www.recycle-more.co.uk



Spirit clocks are produced in China by Peers Hardy. UK ADDRESS Peers Hardy UK Ltd, Precision House, Starley Way, Birmingham, B37 7GN, UK, EU ADDRESS Peers Hardy UK LTD, C/O Global E-commerce Experts, Rijnlanderweg 766, Unit H, 2132 NM, Hoofddorp, Netherlands

**Customer services: 0121 524 1400 (Monday - Friday 9:00am - 4:00pm)
customerservice@peershardy.co.uk**