



#### EN LCD ALARM CLOCK OPERATING INSTRUCTIONS

Thank you for your purchase of this quality clock. Please read these instructions carefully and keep in a safe place for future reference.



#### ACTIVATING THE CLOCK

Insert 3 X AAA batteries into the battery compartment, taking care to observe the polarity.

#### SETTING THE TIME

Press and hold the TIME SET button and press H button to set the hour, ensuring AM/PM is set correctly. Press and hold the TIME SET button and press M button to set the minutes.

#### SETTING THE ALARM

Press and hold the ON/OFF button and press H button to set the hour, ensuring AM/PM is set correctly. Press and hold the ON/OFF button and press M button to set the minutes.

#### TO TURN ON/OFF ALARM

Press the ON/OFF button to turn on/off. When the alarm is activated the bell icon will show.

#### USING THE SNOOZE FEATURE

When the alarm sounds, press the SNOOZE/LIGHT button to snooze the alarm for 5 minutes. The Zz icon will flash. To stop the snooze function, press any button (except the Snooze/Light).

#### TO USE THE DISPLAY LIGHT

Press the SNOOZE/LIGHT button to activate the display light.

#### CHANGING THE BATTERIES

It is recommended that you replace the batteries annually even if the product is still running. Only use 3 X AAA (1.5V) Alkaline batteries in this clock. Do not mix old and new batteries, different types or brands. Remove the batteries if the clock is stored or not in use. Remove exhausted batteries from the product.

**Warning:** Do not recharge non-rechargeable batteries. Please dispose of used battery in a responsible manner. For more information please contact your local authority.

#### MAINTENANCE

A soft cloth may be used to clean your clock. Do not use any corrosive cleaner or chemical solutions on the clock. Keep the clock clean and dry to avoid any problems.

#### YOUR GUARANTEE

Your clock is guaranteed for 2 years from the date of purchase against any faults arising from defective materials or manufacture. Damage caused through careless handling, misuse or in transit is expressly excluded. Should this clock fail within 2 years please return it to your retailer.