

# Liberty House Kids Scandi Height Adjustable Table and Chair Set

Item Code: LHT8833

**AGE 2-8**  
ADULT ASSEMBLY REQUIRED



**General advice:** Please read the instructions carefully, check whether all parts exist, and assemble them accurately according to the instructions. Please keep the instructions after assembly.

**Storage:** Wipe clean with a damp cloth to ensure that the product is completely dry and tidy before storing. Store in a dry and ventilated area to prevent mildew.

**Optional:** Anti-slip pads are supplied with the table and chair (to reduce sliding and noise). These are self-adhesive and can be fixed to the base of the table legs and chair legs. These anti-slip pads are not suitable for outdoor use.

**Note:** Keep children away when assembling. We would recommend that children are not left unattended while using this product.

## TABLE PRODUCT PARTS

 Wooden Table Top x 1	 Main Table x 1	 Table Leg x 4	 Positioning Part x 2
 Hanging Rail x 1	 Non-slip feet for chair legs x 4	 Storage Tray x 2	

## CHAIR PRODUCT PARTS

 Chair Back Rest x 1	 Chair Seat x 1	 Chair Leg x 4	 Non-slip feet for chair legs x 4
---	--	---	--



## WARNING

1. Do not try to use the product before it is installed.
2. If any parts are damaged or lost, do not use them.
3. Please install according to the instructions.
4. Keep away from open fire and other heat sources.
5. Avoid children leaning on the product to avoid accidents and falls.
6. When using, make sure the product is firmly installed before use.

## HEIGHT ADJUSTABLE LEGS




The table and chair legs are both height adjustable to 3 different heights to grow with your child.

The table can be adjusted from H490mm, H520mm, H550mm.

Simply grip the table or chair leg as pictured and press in the locking button to move the leg to a new height position.

## TABLE ASSEMBLY



## CHAIR ASSEMBLY

