














Assembly Instruction 3182509

Read carefully before use and retain for future reference

- Check fixings periodically and re-tighten if necessary
- Recommend 2 people for assembly

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| (A1) 50x43x2cm | (A2) 49x24x2cm | (A3) 28x28x2cm | (A4) Ø30x25.5cm | (A5) 35.5x15.5x2cm | (B1) Ø7.5x43 -4cm | (B2) Ø7.5x37 -1.5cm | (B3) Ø5.5x30 -1.5cm | (B4) Ø7.5x27 -1.5cm | (C1) M8x40mm | (C2) M8x20mm | (C3) |
|  |  |  |  |  |  |  |  |  |  |  |  |
| 1X | 1X | 1X | 1X | 1X | 1X | 1X | 2X | 1X | 4X | 2X | 1X |



If you need help or have damaged or missing parts, call the Argos Aftersales Helpline: 03456 400 800

Argos Limited, London, EC1N 2HT, UK.

Argos (N.I.) Ltd, Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.

Warning! Assembly by an adult