

© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. App Store is a service mark of Apple Inc. Google Play is a trademark of Google LLC. Other trademarks are for reference purposes.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à [arlo.com/docs](http://arlo.com/docs).

(If this product is sold in Canada, you can access this document in Canadian French at [arlo.com/docs](http://arlo.com/docs).)

For regulatory compliance information including the EU Declaration of Conformity, visit [www.arlo.com/about/regulatory/](http://www.arlo.com/about/regulatory/).

**CE** Arlo Technologies Intl. Ltd.  
Ground Floor, Building 3  
University Technology Center  
Curraheen Road, Cork, T12 EF21  
Ireland

Arlo Technologies, Inc.  
2200 Faraday Avenue, Suite 150  
Carlsbad, CA 92008 USA

March 2021



201-50567-01



# Essential Video Doorbell Wire-Free & Chime 2 Quick Start

Hello! You're just a few steps away from getting your Essential Video Doorbell Wire-Free & Chime 2 up and running.

1

Charge the battery to 100%. The battery LED lights red during charging, then turns green when the battery is fully charged.

2


Download the Arlo app from the App Store or Google Play.




3

Follow the step by step instructions in the Arlo app to install your doorbell and Chime 2.


# What's in the box




Doorbell and plate  
(these parts are  
attached)



Angled  
mounting  
plate



Rechargeable  
battery



Chime 2




Release pin  
(keep in a  
safe place)




Wall screws  
and anchors



Battery charging cable  
(works with most  
power adapters)



Optional wire extensions, wire  
fasteners, and extra screws



# Tools

- A Phillips screwdriver is required to install the doorbell (not provided).
- You might also benefit from having a drill and a level.

# If you wire your doorbell

If you choose to hardwire your wire-free Essential Video Doorbell, the voltage must be 8 – 24VAC and a 10VA transformer is required.

If your voltage doesn't meet the power requirements, and you need to install or upgrade a transformer, contact a licensed electrician or visit [arlo.com](http://arlo.com) for information about installation services.

# Need help?

We are here for you.

Visit [www.arlo.com/support](http://www.arlo.com/support) for quick answers and resources:

- How-to videos
- Troubleshooting tips
- Additional support resources