Koba

habitat®





A Safety and Care Advice

Product Details HAB KOBA RATTAN SOFA 3369229

Care and maintenance

• Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.

• From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.

• Use a dry cloth to clean the product, furniture polish is not recommended.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Additional Guidance

- This product is compliant to EN 12520, EN 1022
- Maximum user weight 110 kg
- This product has been supplied with additional felt feet pads thats can be used to help level up furniture on uneven floors

Sainsburys Argos Care Guide

- Periodically check and re-tighten feet where required.
- Keep sofa/chair out of direct sunlight to avoid discolouring.
- Do not place the furniture in a conservatory, excessively dry or humid conditions.
- Avoid sharp items such as toys, jean rivets and buckles coming into contact with the uphosterly as these can easily snag, tear or pull the fabric.
- To maintain the appearance and durability of your suit, restrain children and pets from climbing and jumping on the sofa.
- Rattan is natural material and can display natural marks and characteristic such as colour deviation. These are natural features not faults.