



CUGGL 4 WHEEL DELUXE PUSHCHAIR

IMPORTANT! KEEP THE INSTRUCTION FOR FURTHER REFERENCE

717/3514

cuggl 



33lbs

15kg

up to

Suitable from birth to 36 months.

Important-Please read the instruction fully before starting assembly

If you need help or have further question, call the Customer Helpline **03456 400 800**




Safety Information

Important-Please read the instruction before assembly and keep it for further reference

Thank you for choosing our product. Please always read all the instructions provided carefully before use and remember, your child's safety may be affected if you don't follow these instructions. The stroller is suitable for children under 36 months. The max load of the stroller is 15kgs. Never overload.

- **WARNING:** Do not use if any part is broken, torn or missing .
- **WARNING:** Never leave your child unattended.
- **WARNING:** Always use the restraint system.
- **WARNING:** It may be dangerous to leave your child unattended.
- **WARNING:** This seat unit is not suitable for children over 36 months.
- **WARNING:** Accessories which are not approved by the manufacturer shall not be used.
- **WARNING:** Avoid placing the stroller near naked heat sources such as electric bar fires, gas fires, etc. or where a child could gain access to any other kinds of hazards.
- **WARNING:** Always use the harness provided and make sure the harness is correctly fitted.
- **WARNING:** Ensure that all the locking devices are engaged before use.
- **WARNING:** The brake must be engaged when placing and removing the children.
- **WARNING:** This product is not suitable for running or skating.
- **WARNING:** To avoid injury ensure that your child is kept away when unfolding and folding this product.
- **WARNING:** Do not let your child play with this product.
- **WARNING:** Use the stroller for only one child at a time.
- **WARNING:** The maximum permissible loading for shopping basket is 5 kg.
- **WARNING:** For new born baby, please use the most reclined position as the baby does not have ability to control its head.
- **WARNING:** Only replacement parts supplied or recommended by the manufacturer/distributor shall be used
- **WARNING:** Any load attached to the handle and/or on the back of backrest and/or on the sides of the stroller will affect the stability of the stroller.


Name of parts




Components

If you need help or have further question,
call the Customer Helpline **03456 400 800**


Please check if you have all the parts listed below before starting assembly



【 Front wheels 】



【 Bumper bar 】




【 Rear wheels 】

Assembly Instructions

Step 1


Unfold frame:
Release the folding hook, open the frame and take out the bumper bar and wheels.
Open frame fully until a 'click' is heard.

Folding Hook



Step 2


Lift up the stroller handle with both hands until the stroller frame is locked in the upright position.



Step 3

Assemble the bumper bar:
Insert the end of the bumper bar into adaptor on each side of the hinge.

Bumper Bar




Adaptor

Assembly Instructions

Step 4

Assemble the front wheel:
Press down the lock pin on the front tube, insert the front tube into the adaptor of the front wheel until you hear the click sound.

Caution: Make sure the wheels are properly installed before using the stroller.



Step 5



Press the button at the middle of the rear wheel to install the rear wheels.

Note: make sure it is fully engaged after wheel installation

Insert rear tube into the rear wheel plastic house until hear 'click' sound.

NOTE: Pull on the rear wheel to ensure that it is securely attached to the stroller.


To remove, push release button and pull wheel from hub.



User Instructions

Step 1


Adjust the backrest:
As shown, one hand hold the end of webbing strap, another hand pinch the adjusting buckle and pull it to move backrest to desired position.



User Instructions

Step 2

The leg-rest on the stroller can be adjusted to two positions. Press the trigger on both side of the leg-rest to adjust the position of leg-rest.




Step 3

Slide the shoulder strap buckle ① into the housing of the waist strap buckle ②.

Repeat for the other side. Insert the completed buckle ③ into the buckle housing ④ until it engages securely in place. Repeat for the opposite side.

To release buckle, press centre button on buckle housing ④.




WARNING! Always use the harness and ensure it is correctly fitted securely while child is in the seat.

Step 4

Folding the Stroller

First, ensure canopy is closed and basket is empty, pull the locks on both sides of the stroller to release the folding mechanism. Press hand bar downwards, once folded ensure the folding lock is engaged.

Attention: Adjust the backrest to the flat position before folding the stroller.



Care and Maintenance

General

This pushchair was designed and manufactured with qualified materials and craftsmanship. Always use the safety harness.

Always check your pushchair for bullet points. Lubricate moving parts regularly, especially the wheels, and lower parts of the chassis that tend to collect dirt.

Inspect regularly for:

- Worn parts, torn materials or stitching .
- Loose screws, bent or broken frame parts .
- Broken, damaged or missing parts.

Should any of the above be evident do not use and contact the Helpline:03456 400 800 for advice.

Care and Maintenance:

Fabric parts may be cleaned in accordance with the fabric care labels. Do not machine wash.

Seat: Sponge clean only

Canopy/Basket:Hand wash only.

Do not leave the stroller exposed to heat i.e. by a radiator or in direct sunlight.

If the stroller chassis parts have been exposed to salt water we recommend that they be rinsed down with fresh (tap) water as soon as possible afterwards.

Do not fold or store the product while wet and never store in a damp environment as this can cause mildew to form.

If you need help or have further question, call the Customer Helpline **03456 400 800**

This pushchair has been designed to comply with the EN1888:2012.

Country of origin: China

Argos LTD, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW