


# Pair of button back chairs

Assembly instructions - Please keep for future reference

3898329

3923531



## Dimensions

Width - 57.5cm

Depth - 61cm

Height - 95cm

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



# Safety and care advice

## Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.
- Improper use of electrical tools will crack the components.
- Dispose of all packaging carefully and responsibly.
- **WARNING!** Contains Silica Gel Desiccant. Discard safely away from babies and children.



## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


## Handy Hints

- Assemble all parts and bolts loosely during assembly, once the product is complete you should fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.


**Note:** If required, the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

# Components - Panels

Please check you have all the panels listed below



Legs and hardware are stored inside the chair behind the bottom coverage underneath



**1** Main body x1  
(57.5x61x59.5cm)

**2** Front leg x2 (4.3x4.3x43cm)

**3** Back leg x2  
(4.3x3.5x43cm)

# Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Bolt x8 (M8x50mm)




Washer x8 (Ø22xØ8.2x1.5mm)




Allen key (4mm)

## Tools required




Phillips screwdriver  
(medium & large)



Flatblade screwdriver  
(medium)

**Ruler** - Use this ruler to help correctly identify the screws




If you have damaged or missing components, call the **Customer Helpline: 03456 400800**

# Assembly instructions


## Step 1

Insert front leg **2**  
into the main body **1**  
then tighten bolts **A** and  
washer **B** using allen  
key **C**.



## Step 2

Insert back leg **3**  
into the main body **1**  
then tighten bolts **A** and  
washer **B** using allen  
key **C**.



**Assembly is complete!**