

Colourmatch Gemini Bar Stool


Assembly Instructions - Please keep for future reference

392/4839

414/8793

414/6489

391/9655



Dimensions

Width - 52cm
Depth - 43cm
Height - 99.5cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 640 0800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Parts of the assembly will be easier with 2 people.

- During assembly do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.

- Do not stand on the stool.

- Do not use this stool as a step ladder.



power drill is set on a low torque setting.

- Unit weight: 4.25 kgs.

- Maximum safe weight of user: 110kgs.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints


- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.

- Regularly check and ensure that all bolts and fittings are tightened properly.


Components - Parts

If you have damaged or missing components, call the
Customer Helpline: Argos = 0345 640 0800


Please check you have all the parts listed below




1 Seat
(52 x 42 x 29cm)



2 Stretcher
(Ø2.2 x 38.2 x 38.2cm)



3 Upper leg
(72 x 52.5 x 3cm)









4 Lower leg
(72 x 51 x 3cm)


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>M6 x 35mm Bolt x 8</p>	<p>B </p> <p>M6 x 25mm Bolt x 1</p>	<p>C </p> <p>Nut x 1</p>
<p>D </p> <p>Curved washer x 4</p>	<p>E </p> <p>Allen key x 1</p>	<p>F </p> <p>Spanner x 1</p>

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1



Attaching legs

Position the upper leg **3** and lower leg **4** as shown. Align holes and fix using bolt **B** & nut **C**.



Important:

Tighten bolt and nut using allen key **E** and spanner **F** but do not fully tighten at this stage.



Step 2



Attaching stretcher

Position the stretcher **2** between the legs as shown. Align holes and fix using bolts **A**.



Important:

Tighten bolts using allen key **E** but do not fully tighten at this stage.



Assembly Instructions

Step 3


Aligning the legs

Place the leg frame on a flat surface.

Fully tighten bolt **B** and nut **C** assembled in step 1 first using allen key **E** and spanner **F**.

Carefully make adjustments to the leg frame to ensure the legs are flat even on the floor.

Then fully tighten bolts **A** on stretcher **2** using allen key **E**.



Step 4

Attaching seat

Place the seat **1** face down on a flat protected and raised surface.

Position the leg frame on the seat as shown. Align the holes and fix using bolts **A** and curved washers **D**. Tighten the bolts using allen key **E**.






Important:

Do not over tighten bolt **A**.

Carefully turn over the bar stool.

Assembly is complete.



If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 640 0800