

# 3 SEATER METAL SWING CHAIR

Assembly Instructions - Please keep for future reference

7495498



## Dimensions

Width - 176cm

Depth - 112cm

Height - 150cm

**IMPORTANT-PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY**

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6403030

Retailer: Argos

Address: 489-499 Avebury Boulevard Saxon Gate West. Central Milton Keynes Bucks. MK9. 2NW

# Safety and Care Advice

- Check you have all the components and tools listed on page 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.

- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Assemble the unit as close to its final position (in the same room) as possible.
- Parts of the assembly will be easier with 2 people.
- If using power tools, please follow the safety instructions supplied with the tools.
- This product is for domestic use.



• We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.
- Warning: The unit weights approximately 18 kgs.  
Safety weight: 330kgs per seat

**Please lift with care.**





## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.
- Suggestion: When you do not use it, find one suitable cover on it.
- Don't fully tighten all screws until assembly is complete.
- Make sure each screw match the corresponding figure to ensure correct assembly.

# Components - Parts

If you have damaged or missing components, call the Customer Helpline: 0345 6403030





Please check you have all the parts listed below

<p>1</p>  <p>Front Leg x 2</p>	<p>2</p>  <p>Rear Leg x 2</p>	<p>3</p>  <p>Upper Connect Tube x 1</p>	<p>4</p>  <p>Canopy U-shape Tube x 2</p>
<p>5</p>  <p>Canopy Tube x 2</p>	<p>6</p>  <p>Seat Cushion x 1</p>	<p>7</p>  <p>Armrest x 2</p>	<p>8</p>  <p>Canopy x 1</p>
<p>9</p>  <p>Hanging Tube x 4</p>	<p>10</p>  <p>Lower Connect Tube x 1</p>	<p>11</p>  <p>Side Connect Tube x 2</p>	<p>12</p>  <p>Seat x 1</p>


# Components - Fittings

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required. Bradawl, spanner and screwdriver are required but excluded.

<p>A</p>  <p>M10x40 Plastic Switch x 2</p>	<p>B</p>  <p>M8x90 Bolts x 4</p>	<p>C</p>  <p>M8 Nuts &amp; Washers x 4</p>	<p>D</p>  <p>M6x60 Bolts x 6</p>
<p>E</p>  <p>M6 Nuts &amp; Washers x 17</p>	<p>F</p>  <p>M6x35 Bolts x 2</p>	<p>G</p>  <p>M6x45 Bolts x 6</p>	<p>H</p>  <p>M6x55 Bolts x 2</p>
<p>I</p>  <p>Spring hook x 2</p>	<p>J</p>  <p>Foot x 4</p>	<p>K</p>  <p>M8 Cap x 4</p>	<p>L</p>  <p>M6 Cap x 17</p>
<p>M</p>  <p>Plastic Sleeve x 8</p>	<p>N</p>  <p>M6x25 Screw x 1</p>	<p>O</p>  <p>Wrench x 1</p>	<p>P</p>  <p>Allen Key x 1</p>

Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions

## Step 1

2 person required


A: Connect the 2 parts of upper connect tube **3** together and use bolts **G** washers and nuts **E** to fasten.

B: Then fix front leg **1**, upper connect tube **3** and rear leg **2** together using bolts **B** washers and nuts **C**.

C: Fix the feet **J** to the legs.

**FULLY TIGHTEN ALL NUTS.**

Then use nut covers **K** **L** to cover the nuts  
(See fig .1)




## Step 2

Fix side connect tube **11** between front leg **1** and rear leg **2** using bolts **G**, washers and nuts **E**.

**FULLY TIGHTEN ALL NUTS.**

Then use nut covers **L** to cover the nuts  
(See fig .1)




## Step 3

A : Connect the 2 parts of lower connect tube **10** together and use screw **N** to fasten.

B : Fix lower connect tube **10** between two rear legs **2** using bolts **D**, washers and nuts **E**.

**FULLY TIGHTEN ALL NUTS.**

Then use nut covers **L** to cover the nuts  
(See fig .3)



If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6403030

Retailer: Argos

Address: 489-499 Avebury Boulevard Saxon Gate West. Central Milton Keynes Bucks. MK9. 2NW

# Assembly Instructions

## Step 4


A: Cap the both ends of the hanging tubes **9** by plastic sleeve **M**.

B: Fix the armrest **7** and hanging tubes **9** to the seat **12** using bolts **D**, **F**, **H**, washers and nuts **E**.

**FULLY TIGHTEN ALL NUTS.**

Then use nut covers **L** to cover the nuts (See fig .4)

**⚠ Important:** Before open the seat, please adjust the textiene to right position and differentiate the seat and back side.




## Step 5

A: Use spring hook **I** to hang the seat, then put seat cushion **6** on the seat.

B: Use plastic switch **A** to fix the canopy U shape tube **4** to the both sides of the upper connect tube. (See fig .5)


C: Put the seat cushion **6** to the seat **12** and fixed by bendage.



## Step 6

Insert the canopy tube **5** to the canopy **8** then connect it to the canopy U shape tube **4**.

(See fig .6)



If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6403030

Retailer: Argos

Address: 489-499 Avebury Boulevard Saxon Gate West. Central Milton Keynes Bucks. MK9. 2NW