


# AVR Bentwood Chair

Assembly Instructions - Please keep for future reference

411/1634



## Dimensions

Width - 48cm

Depth - 53cm

Height - 81cm

**Important - Please read these instructions carefully before starting assembly**

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



# Safety and Care Advice

**Important - Please read these instructions carefully before starting assembly**

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small part could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- Unit weight: 3.9 kgs.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.
- Maximum safe weight of user: 110 kgs.
- Do not stand on the chair.
- Do not use the chair as a step ladder.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


## Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.

# Components - Parts

If you have damaged or missing components, call the **Customer Helpline: 03456 400800**


Please check if you have all the parts listed below



**1** Seat (42 x 40 x 1.2cm)



**2** LegA (64 x 40.5 x 1.9cm)











**3** LegB (64 x 40.5 x 1.9cm)

# Components - Fittings

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p><b>A</b> </p> <p>M6x32mm Bolts x 4</p>	<p><b>B</b> </p> <p>M6x40mm Bolt x 1</p>	<p><b>C</b> </p> <p>M6 Flat washer x 2</p>
<p><b>D</b> </p> <p>M6 Spring washers x 5</p>	<p><b>E</b> </p> <p>23x28x32mm Nut plastics x 4</p>	<p><b>F</b> </p> <p>M6 Allen key x 1</p>
<p><b>G</b> </p> <p>M6 Nut x 1</p>	<p><b>H</b> </p> <p>M6 Spanner x 1</p>	

**Ruler-** Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170



The screws length is measured from the head to the point (30mm screw shown).

# Assembly Instructions

## Step 1


### Attach the legs

Upside down the seat **1** on a protected table.

Attach the shorter end of bolt **B** with flat washer **C** into the center hole of seat **1**.

Slide the nut plastics **E** onto legs **2** & **3** as shown in the figure.


Attached legs **2** & **3** to the seat **1** using bolts **A** with spring washers **D**, and then tighten with allen key **F**.



## Step 2

### Fix the centre bolt

Fix the bolt **B** with a flat washer **C** and a spring washer **D** and a nut **G** to the seat, tighten with a spanner **H**.



**Assembly is complete**

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**