

# OSCAR BOOKCASE


Assembly Instructions - Please keep for future reference

408/5887

412/1947

413/7728

418/2388



## Dimensions

Width - 83cm  
Depth - 29 cm  
Height - 80 cm

**Important - Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, call the **Customer Helpline: 0345 6400 800**



## Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

Check you have all the components and tools listed on pages 2 and 3.

Remove all fittings from the plastic bags and separate them into their groups.

Keep children and animals away from the work area, small parts could choke if swallowed. Make sure you have enough space to layout the parts before starting.

Assemble the item as close to its final position (in the same room) as possible.

Assemble on a soft level surface to avoid damaging the unit or your floor.

Assembly requires 2 people.

Keep this instructions for future use.

Do not stand or put excessive weight on the product, this could cause damage.



We do not recommend the use of power drill/drivers **for inserting screws,**

as this could damage the unit. Only use hand screwdrivers and Allen keys.

Dispose of all packaging carefully and responsibly.

## Care and maintenance

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.


From time to time check that there are no loose screws on this unit.

This product should not be discarded with household waste. Take to your local authority waste disposal centre.


# Components - Parts

If you have damaged or missing components.  
call the **Customer Helpline**: 0345 6400 800


Please check you have all the parts listed below




- 1** Divider x 2  
(28.7x27.6x3cm)




- 2** shelf x 2  
(79.9x28.8x3cm)




- 3** Side panel (small) x 2  
(28.7x18.7x3cm)



- 4** Side panel (large) x 2  
(49.3x28.9x3cm)



- 5** Top panel x 2  
(41.5x29x3cm)



- 6** Base panel x 2  
(83x29x3cm)

# Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 0345 6400 800**

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p><b>A</b></p>  <p>Metal dowel x 24</p>	<p><b>B</b></p>  <p>Locking nut x 24</p>	<p><b>C</b></p>  <p>Wooden dowel x 28</p>
<p><b>D</b></p>  <p>Sticker x 28</p>	<p><b>E</b></p>  <p>EVA pad x 8</p>	<p><b>F</b></p>  <p>Wall strap x 2</p>
<p><b>G</b></p>  <p>12mm Wood screw x 2</p>	<p><b>H</b></p>  <p>40mm Wood screw x 4</p>	

## Tools required




Ruler/tape measure



Phillips screwdriver  
(Not supplied)

## Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions

## Step 1


### Preparing divider and shelf

Place divider **1** and shelf **2** flat onto the floor with the fixing holes facing up.

Screw metal dowels **A** into one end of shelf **2** as shown.

**Note:** Screw metal dowels as far as shown. Do not overtighten


Insert wood dowels **C** into panels **1** and **2** as shown.



## Step 2

### Assembling divider

With help, assemble divider **1** to shelf **2** using screws **H**.



# Assembly Instructions

## Step 3


### Preparing side panels

Place small side panel **3** and large side panel **4** flat on the floor with fixing holes facing up.

Screw metal dowels **A** into large side panel **4** as shown.

**Note:** Screw metal dowels as far as shown. Do not overtighten

Insert wood dowels **C** into panels **3** and **4** as shown.



## Step 4


### Assembling side panels

Carefully locate side panels **3** and **4** into position as shown.

Insert locking nuts **B** into the holes in shelf **2** and small side panel **3** as shown.

Turn locking nuts **B** clockwise to secure.

Stickers **D** can be used to cover the fixing holes.



# Assembly Instructions


## Step 5

### Preparing top panel and base panel

Place top panel **5** and base panel **6** flat on the floor with the fixing holes facing up.

Screw metal dowels **A** into both panels as shown.

**Note:** Screw metal dowels as far as shown. Do not overtighten.



## Step 6


### Assembling top panel and base panel

Carefully locate top panel **5** and base panel **6** into position as shown.

Insert locking nuts **B** into the holes in divider **1** and side panels **3** and **4** as shown.

Turn locking nuts **B** clockwise to secure.

Stickers **D** can be used to cover the fixing holes.



# Assembly Instructions

## Step 7


Repeat Steps 1 to 6 to assemble the second shelf unit.

**a :** Depending on the configuration of shelves you select, self adhesive EVA pads **E** can be used on the base.


**b :** With help, carefully lift the shelves into position.

 **Warning:** The shelves are heavy. Lift with care.

**a:**



**b:**



# Assembly Instructions

## Step 8

It is recommended that the unit is fixed to the wall to ensure stability.

Assemble wall straps **F** to the back edge of top panel **6** using screws **H**.

With help, move the unit to the desired location.


Mark the fixing hole locations on the wall and remove the unit.

Drill the wall and fit suitable plugs for your wall type.

**Note:** Wall plugs are not supplied.

 **Warning:** Before drilling. Check the wall for hidden pipes or cables. Re-position the unit and secure the wall straps to the wall.

**Note:** Screws are not supplied.



**Assembly is complete.**

If you need help or have damaged or missing parts, call the **Customer Helpline: 0345 6400 800**  
Home Retail Group. 489-499 Avebury Boulevard. Saxon Gate West. Central Milton Keynes. MK9 2NW