


QUICK START

please read the instructions that come with your HotCup™ water dispenser and follow all safety warnings before use.


HOT
CUP® Breville

1



Step 1: open the lid and fill with water

2




Step 2: replace on the power base

Selecting the right mug size

- The mug you use needs to be big enough to hold the water your HotCup™ dispenses each time it is used.
- Select your mug and place it on the drip tray under the spout.
- If the mug is too small, it will overflow when your HotCup™ dispenses water. **Don't worry, the drip tray will safely catch any spills!**
- Simply try a bigger mug until it can hold the water dispensed.

3



Step 3: plug in your HotCup™ water dispenser

5



Step 5: boiling water is dispensed

4



Step 4: press the on/off button until it lights