
# 3DS/3DS XL Mains Charger - User Guide

Please read the instructions below before using the Adaptor.

#### Features:

- 1. Lightweight, durable and easy to carry
- 2. Ideal for home or travel
- 3. 1 metre cable length



### Operation:

Check the instructions supplied with your console before charging.

Connect the 3 way cable to the USB adaptor as shown above. Connect the appropriate plug of the three available to your console and switch on the power at the mains socket.

Please Note: This product must only be used to charge one console at a time.

## Rating:

Input: 100-240V ~ 50/60Hz, 150mA Maximum Output : 5V ... 1000mA

#### WARNING:

- 1. Only Charge one console at a time.
- 2. For indoor use only.
- 3. Don't attempt to open the adaptor
- 4. Be careful not to crush or bend cable or adaptor.
- 5. If damaged in anyway do not use.
- 6. Do not expose unit to heat sources such as radiators and heaters.
- Keep this product dry and avoid contact with any liquids.
- 8. Use of the adaptor by children should only be allowed with the full supervision of
- 9. an adult
  - When the device is charging, be careful not to pull the power cord.
- 10. Ensure to connect the adaptor to the correct voltage (100-240V  $\sim$  50/60Hz)



Waste electrical and electronic products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority for recycling advice.





## PRODUCT GUARANTEE

This product is guaranteed against manufacturing defects for a period of



This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will be either replaced, refunded or repaired free for charge where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provision:

- The guarantee does not cover accidental damage, misuse, cabinet parts knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual.
- It must be used for domestic purpose.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to, and does not diminish your statutory or legal rights.

Guarantor: Argos Ltd 489 - 499 Avebury Boulevard Central Milton Keynes MK9 2NW