



BLOWN AWAY HAIR KIT


Lee Stafford
1 YEAR GUARANTEE

4539522 Instruction Manual

My BLOWN AWAY HAIR KIT is everything you need for that big voluminous Bardot blow-out. The secret weapon is my stay put rollers for extra lift at the root. The powerful 2200W hairdryer with cool shot sets your volume in place for bigger, fuller, fatter hair!

IMPORTANT SAFETY POINTS

To reduce the risk of fire, burns, electric shock or other injuries, careful study of the following important safety precautions is strongly recommended:

For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30mA is advisable. Please consult your local electrician for advice.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack experience or knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.


ALWAYS

- ✓ **ALWAYS** use the unit only for its intended use as described in this manual. Only use attachments recommended in this pack.
- ✓ **ALWAYS** take care to avoid contact between hot surfaces and bare skin, particularly at the face & neck.
- ✓ **ALWAYS** ensure the appliance is switched off, unplugged from the mains and it has cooled down before storing.
- ✓ **ALWAYS** regularly check the mains cord for damage from time to time. If damaged, discontinue use immediately and do not use until the appliance has been inspected and approved by a qualified electrician.
- ✓ **ALWAYS** clean before storing away.
- ✓ **ALWAYS** keep mains cord away from hot or heated surfaces.
- ✓ **ALWAYS** store in original box in a cool, dry place.

NEVER

- ✗ **NEVER** use this product if it is not working correctly, if it has been dropped or damaged or dropped into water or any other liquid or if it has a damaged plug or mains cord. If it has the unit must not be used.

- ✗ **NEVER** use with wet hands.

- ✗  **NEVER** use this product near bathrooms, showers, basins or other vessels containing water and do not immerse in water or any other liquids.

- ✗ **NEVER** place the unit near heat sensitive materials.
- ✗ **NEVER** leave unattended when plugged in and operating.
- ✗ **NEVER** wind the mains cord around the handle when hot or while storing.
- ✗ **NEVER** store while still connected to the mains.
- ✗ **NEVER** attempt repairs yourself. Repairs to electrical appliances should only be performed by a qualified electrician. Improper repairs may place the user at serious risk and will invalidate the guarantee.
- ✗ **NEVER** carry or suspend the appliance by the power lead.

IMPORTANT SAFETY POINTS

A 13 amp BS1362 ASTA approved fuse must be fitted.

Before switching on, make sure that the voltage of your electricity supply is the same as that indicated on the rating plate. Connecting it to any other power source may cause damage.

This product may be fitted with a non-rewirable plug. If it is necessary to change the fuse in the plug, the fuse cover must be refitted. If the fuse cover becomes lost or damaged, the plug must not be used until a suitable replacement is obtained.

If the plug has to be changed because it is not suitable for your socket, or due to damage, it should be cut off and a replacement fitted, following the wiring instructions shown. The old plug must be disposed of safely because inserting it into a socket could cause an electrical hazard.

The wires in the mains cable of this product are coloured in accordance with the following code:

Blue = Neutral **Brown = Live**

If the markings on the terminals of your plug do not correspond to the colours shown of the wires in the mains cable, proceed as follows:



The wire which is coloured **Blue** must be connected to the terminal which is marked **N** or coloured **Black**.

The wire which is coloured **Brown** must be connected to the terminal which is marked **L** or coloured **Red**.

DO NOT connect any wires to the earth terminal.



This symbol indicates that this is a 2-core appliance is Class II and does not require an earth connection.



Comes with:

- Sectioning comb
- Sectioning clips
- 2 Velcro Rollers
- Hair brush for styling
- Lee Stafford storage/travel bag

Due to our policy of continuous improvement, the actual product may differ slightly from the one illustrated in this booklet.

BLOwn Away HAiR KiT

PRODUCT FEATURES

- 2200W DC motor.
- 2 speed and 3 heat settings for ultimate control.
- Removable concentrator for directing airflow.
- Cool shot to set your style.
- Removable rear grille cover.
- Comes with a storage/travel bag, a tail comb for easy sectioning, a hair brush, sectioning clips and 2 fantastic large Velcro stay put rollers for lift and volume.
- 1 year guarantee.

Thank you for choosing Lee Stafford. Please read and retain these instructions before operating and for future reference.

Using your BLOwn Away HAiR KiT

PREPARING FOR USE

- Please read and retain these instructions before operating and for future reference.
- Remove all packaging and keep safe.
- For domestic use only.

OPERATION

This unit operates on a main AC 220-240~50/60Hz 1800-2200W.

INSTRUCTIONS FOR USE

- Towel dry your hair after washing, and detangle with a large tooth comb from root to tip.
- Plug the appliance into a suitable mains socket.
- Ensure the voltage being used is the correct voltage for this product.
- You can alter the heat and speeds settings via the switches and button on the handle.
- Section the hair into manageable sections using the tail comb and grips, this will help to create a perfect long lasting blow dry.
- Use high heat and speed for initial drying.
- Use low heat and speed as hair begins to dry and for styling.
- You can use the concentrator nozzle to direct heat and control the airflow.
- Use the Velcro stay put rollers for lift at the root and body throughout your hair.
- Use the cool shot to set your style in place.
- When you release the cool shot button, the dryer will return to normal operation.
- After use, switch off and unplug the appliance.
- Allow unit to cool before storing away.
- Always keep the rear of the appliance away from the hair during use to prevent it being drawn in through the rear cover.

LEE'S TIPS

- Keep the cuticles flat by pointing the hair dryer downwards and aiming the airflow down the hair shaft.
- When the Velcro stay put rollers are in place, give your hair a spritz with my FAT Flexible HoLD HAiRSPRaY to prolong your style.

CLEANING AND MAINTENANCE

- The appliance must be unplugged before cleaning.
- Let the appliance cool down before cleaning.
- Wipe the body of the dryer with a soft damp cloth.
- To prolong the motor life it is important to regularly remove dust and dirt from the rear grille.
- Do not use any harsh detergents, abrasives, solvents or cleaners.
- Never immerse in water to clean.

STORAGE

- Ensure the product is completely dry, switched off and unplugged from the mains before storage.
- Store in original box in a cool, dry place.
- Store in a safe place, away from young children.

SERVICING

There are no user serviceable parts inside this appliance.

Always refer servicing to qualified service personnel.

If you drop or damage your product, do not use until it has been inspected and approved by a qualified electrician.

If you require help with using your product contact the Customer Service Helpline on **03456 403 030**.

IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC.

YOUR ONE YEAR GUARANTEE

This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will either be replaced, refunded or repaired free of charge where possible during the period set by the dealer from whom you purchased the unit.

The following conditions apply:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual.
- It must be used only for domestic purposes.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to, and does not diminish your statutory rights.
- Valid in the UK only.

At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.





Lee stafford

"Have Fun, Look wicKed,
Turn iT ON"

Lee
xXx

Lee Stafford, Soho, London
www.leestaffordelectricals.com