


# Nomad


 habitat



## Spare Parts

-  [www.argos-support.co.uk](http://www.argos-support.co.uk)
-  [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk)
-  0370 112 1928

## Customer Support

-  0345 640 2020



# Safety and Care Advice


---

## Product Details

Vinyl Cabinet Oak 3630611  
Vinyl Cabinet Anthracite 4543556

## IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- This product has been constructed to be used in the domestic environment only and not for commercial purposes.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.



- We do not recommend the use of power drill/drivers for inserting screws as this could damage the unit. Only use hand screwdrivers.
- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.

## Care and maintenance

---

- Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.
- Use a dry cloth to clean the product, furniture polish is not recommended.
- From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## WARNING

---

In order to prevent overturning this product must be used with the wall attachment device provided.

## Additional Guidance

---


- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.
- This product is compliant BS4875-7 level 2, EN 14749

# Fittings (Shown to scale)


## Bag 1




**A**  
5 x 50mm Screw x 15  
SCR05050




**B**  
7 x 30mm Screw x 6  
SCR07030




**C**  
7 x 39mm Locking Pin x 24  
SCR07039




**D**  
15 x 12mm Locking Nut x 24  
FIT1512000



**E**  
8 x 30mm Dowel x 6  
PGW0830




**F**  
4 x 18mm Shelf Support x 8  
PGM0418



**G**  
4 x 20mm Screw x 4  
SCR040209




**H**  
4 x 15mm Screw x 16  
SCR04015M (With extra few pieces for spare)




**I**  
6x15mm Screw x 4  
SCR06015-L



**J**  
4 x 14.5mm Screw x 2  
SCR04014



**K**  
4 x 33mm Screw x 2  
SCR04033



**L**  
Wall Strap x 2  
ELSRING10015




**M**  
Wall Plug x 2  
CAP070350



**N**  
Allen Key x 1  
PAR250704-L




**O**  
7 x 1.5mm Door Pad x 2  
PAD0701502




**P**  
6 x 50mm Screw x 2  
SCR06050-L

# Hardware


---




160 x 20mm Handle x 2  
HUM16160207




Door Hinge x 4  
HIG0900048354F



392 x 160mm  
Side post x 2  
PNM1602003922S



758 x 20mm  
Upper Bar x 1  
PRM202007581S




758 x 20mm  
Base Bar x 1  
PRM202007583S




120 x 20mm  
Centre Bar x 1  
PRM20200120N

# Tools required


---




Phillips screwdriver  
(small & medium)



Ruler/tape  
measure




Flat-head screwdriver  
(small & medium)




Eye protection  
(when using a  
hammer or glue)




Small  
hammer



Large hammer



Pencil



Mallet



Set Square



Spirit Level

# Panels


---



1 Top (803 x 397mm)




2 Bottom (803 x 397mm)




3 Right Side (950 x 391mm)




4 Left Side (950 x 391mm)




5 Center (592 x 354mm)



6 Middle (765 x 373mm)




7 Shelf (374 x 353mm) (x2)



8 Upper Shelf (445 x 294mm)




9 Upper Right Support (340 x 296mm)




10 Upper Shelf Support (340 x 296mm)




11 Upper Back (765 x 340mm)



12 Lower Back (765 x 340mm)







13 Right Door (584 x 377mm)






14 Left Door (584 x 377mm)





# 1






# 2



# 3





# 4










# 5






# 6





# 7








# 8






# 9





# 10





# 11






# 12








# 13






# 14




# 15



# 16



## Hinges Adjustment




**A.** Side to side adjustment by clockwise or anticlockwise adjustment.

**B.** Up and down adjustment by adjusting mounting plate slot.

**C.** Front to back adjustment by rotating screw clockwise or anticlockwise.






## NOTE

LOCK THE HINGE AFTER ADJUSTMENT!  
IF NEEDED, ADD 2 SCREWS ON EACH MOUNTING PLATE  
TO STRENGTHEN IT (WITH SPARE SCREWS INCLUDED).






# 17



**WARNING!**  
IN ORDER TO PREVENT OVERTURNING  
THIS PRODUCT MUST BE USED WITH  
THE WALL ATTACHMENT DEVICE  
PROVIDED

**NOTE**  
PLEASE REFER TO THE WALL MOUNTING &  
FIXINGS GUIDE FOR WALL FIXING.



# A Guide to - Wall Mounting & Fixings

## Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using incorrect fixings is the responsibility of the installer.



**Important:** When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


## Hints:

- 1: General rule:**  Always use a larger screw and wall plug if you are not sure.
- 2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

## Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

### No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

### No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

### No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

### No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

### No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

### No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



## Care & Maintenance

**Safety:** Always check the fitting and location to ensure your safety in and around the home.

**Fitting:** From time to time check the fitting to ensure the wall plugs or screws do not become loose.