



OPAL MOSES BASKET FOLDING STAND

Assembly Instructions

**IMPORTANT- READ THE INSTRUCTIONS
CAREFULLY AND RETAIN FOR FUTURE REFERENCE**



Number of people to assemble:

One adult is required to
assemble this item.



15 Minutes.

Need Help?

With assembly instructions
missing or damaged parts

Please Call- 0844 7744644


or Email sales@kinder-valley.com

Assembly Instructions for Kinder Valley Moses Basket Folding Stand

Thank you for choosing this Kinder Valley Moses Basket Folding Stand. In order to build this stand correctly, please follow the instructions carefully.

If you encounter any problems please contact the Kinder Valley helpline: 0844 7744644 or email: **sales@kinder-valley.com**

- This stand is designed for use with a Palm, Maise or Wicker basket of the following sizes: MIN - MAX (L)670-830mm x (W)300-320mm.
- Do not attach anything to the stand that may affect its stability.
- The stand should be inspected regularly for any damage that may affect its safe use.
- Never leave anything in the stand or attached to the sides, that could provide a foothold for other children, or present a danger of strangulation or suffocation. When the stand is not in use it must be folded and stored away from children.
- Store in a cool, dry place when not in use.
- Regularly check that nuts and bolts are secure. Loose fittings can result in snagging clothes or cords posing a risk of strangulation.
- In order to clean, use only a mild detergent and warm water. Do not use bleach or any abrasive substances.
- This stand conforms to BS EN 1466:2014

 **WARNING:** Do not use this stand if any part is broken, torn or missing and use only spare parts approved by the manufacturer.


 **WARNING:** Remove all packaging materials before use.

 **WARNING:** Do not let other children play unattended near moses basket & stand.


 **WARNING:** Use only on firm ground which is on a horizontal level & dry.

Parts List:

A x 2 Leg Set




B x 1 Canvas Dowels supports



C1 x 1 Long Dowel




D x 2 Plastic Rails



C2 x 1 Short Dowel



E x 8 40mm Screws





F x 4 13mm Screws




Step 1:

Attach the canvas dowel supports **B** to the top of the legs **A** (in the hole situated nearest to the groove) ensuring the metal fasteners are on the underside. Ensure the smaller dowel is inserted into the inner legs, and the longer dowel in the outer legs.




Step 2:

Insert 4 x **E** screws into the top of the legs.




Step 3:

Insert **C1** into outer legs.
 Insert **C2** into inner legs.
 Insert 4 x **E** to tighten.



Step 4:

Slide the 2 plastic rails **D** into the grooves at the top of the legs either side, then bend round to slide into the other side and fix into place using 4 x **F**



Please ensure that all nuts and bolts are secure, tighten if necessary.