

# (Little Gem Rocking Stand)

### ASSEMBLY INSTRUCTIONS



Need Help? Call 0844 7744 644 or Email sales@kinder-valley.com

IMPORTANT- Read these instructions carefully before use and keep for future reference.

## Little Gem Rocking Stand Assembly Instructions

#### BEFORE YOU START IMPORTANT - RETAIN FOR FUTURE REFERENCE -READ CAREFULLY

Instructions for safe use:

- WARNING Do NOT attach anything to the stand that may affect its stability.
- WARNING Remove all packaging materials before use.
- WARNING Store in a cool, dry place away from children when not in use.
- WARNING Do NOT let other children play unattended near the moses basket and stand.
- WARNING Use only on firm ground which is horizontal, level and dry.
- WARNING Do NOT use if any part is broken, torn or missing.
- WARNING Only use replacement parts supplied by or approved by Kinder Valley
- WARNING Your product can be cleaned with a damp cloth. Never use harsh abrasives, bleach or strong detergents.

### **FIXTURES & FITTINGS**

CHECK THAT YOU HAVE ALL FIXTURES AND FITTINGS BEFORE ASSEMBLY, AND ENSURE THEY ARE NOT BROKEN.







Step 6

Finally, attach plastic rail  $\blacksquare$  to legs using the 2 x 15mm screws  $\blacksquare$ .

Repeat this step with the remaining plastic rail  $\mathbf{E}$ . The plastic rails have 6 x holes one end and 2 x holes the other to allow for adjustment depending on the size of your moses basket.