
3x3 Pop up Gazebo with Side Panels Waterproof



Spare Parts



Help@ClickSpares.co.uk

0370 112 1928

Customer Support

0345 640 2020



Safety and Care Advice

Product Details

Blue 464/8059

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

- Check you have all the components, fittings and tools listed in this manual.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not Assemble or Dismantle during strong winds.
- This unit is not a permanent fixture - Do not use or leave erected in windy conditions.

- Follow all safety and fire precautions when in or near this gazebo.
- Please note that this gazebo is showerproof and not waterproof.
- Practice assembling and dismantling the gazebo before use to familiarise yourself with the components and fittings.
- Take note of all the components and fittings and ensure you don't forget anything when dismantling.
- Before each use check you have all the components and fittings and that none of them are demaged.

- To prevent the wind blowing into the entrance, position the gazebo so the entrance is away from prevailing winds.
- Ensure the ground is level free from debris and sharp objects that could damage the fabric. Avoid pitching under trees but make use of any nature wind breaks such as hedge rows etc. Heavy winds and rain could damage the gazebo.
- Try to locate the gazebo at least 5-10 meters away from any other campers where possbile.
- This unit weiths approximately 20kgs. **Please lift with care.**

Care and maintenance

- Take care when dismantling the gazebo. Follow the assembly instructions in the reverse order and do not force the frame.
- Never remove the pegs by pulling on the guy ropes, fabric or gazebo legs.
- Ensure all parts of the gazebo are completely dry before repacking.

If necessary unpack the parts when you return home and allow to dry completely before repacking and storing.


- All parts should be cleaned and packed separately. When completely dry gently remove any dirt and debris from the fabric with a soft brush.
- Never use abrasive cleaners or detergens.

Additional Guidance


- The canopy and sides of this gazebo are not fire proof, follow the fire precautions and safety at all the times.
- Do not use naked flames in or around the gazebo there is no cooking area within the gazebo.
- Do not store cooking apparatus, BBQs etc within the gazebo as it may cause a fire hazard.
- Do not smoke or allow smoking in or around the gazebo.

Fittings (Shown to scale)

Bag 1




Components




1 Tent Bag (1250 x 250mm)



3 Top Roof (3000 x 3000mm)



5 Back Panel (3000 x 2000mm)




2 Steel Frame (1200 x 230mm)




4 Side Panel (2) (3000 x 2000mm)

Tools required




Rubber mallet




NOTE: At least 2 people are required for this procedure.


2









NOTE: At least 2 people are required for this procedure.



NOTE: Get into the frame and assemble the cap after putting on the top roof.




























10





WARNING!

IN HEAVY WIND, IF YOU WANT TO LEAVE THE GAZEBO OUTSIDE, PLEASE REMOVE THE SIDE PANELS.



Assembly is completed