
# Nomad







# Safety and Care Advice

### **Product Details**

Radiator Cover Small 4725484

## IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

room) as possible.

unit or your floor.

Assemble the item as close

Assemble on a soft level

to its final position (in the same

surface to avoid damaging the

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• This product has been constructed to be used in the domestic environment only and not for commercial purposes.

### **Care and maintenance**

• Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.

• Use a dry cloth to clean the product, furniture polish is not recommended.

• From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.

• We do not recommend the use of power drill/drivers for inserting screws

as this could damage the unit. Only use hand screwdrivers.

• Parts of the assembly will be easier with 2 people.

• Dispose of all packaging carefully and responsibly.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

### WARNING


In order to prevent overturning this product must be used with the wall attachment device provided.

### Additiona l Guidance


- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightend properly.
- This product is compliant EN 14749

## Fittings (Shown to scale)


## Bag 1



## Hardware



## **Tools required**




#### 

Spirit Level


## Panels


•


1 Top (1022 x 218mm)





2 Bottom (1022 x 196mm)

















## A Guide to - Wall Mounting & Fixings

#### Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



*Important:* When drilling into walls always ) check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


#### Hints:

- 1: General rule: Always use a larger screw and wall plug if you are not sure.
- **2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- **3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- **4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

You can use one of the following types of wall plug if your walls are made


**5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

### **Types of walls**



Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

#### No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.




No.3 "Cavity Fixing" wall plug

of brick, breeze block, concrete, stone or wood.



For use with plasterboard partitions or hollow wooden doors.


#### No.4 "Cavity Fixing-Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.


**Safety:** Always check the fitting and location to ensure your safety in and around the home.

#### No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

#### No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

**Fitting:** From time to time check the fitting to ensure the wall plugs or screws do not become loose.