Larsa © habitat Dining Table



Spare Parts



■ Help@ClickSpares.co.uk

0370 112 1928

Customer Support

0345 640 2020



Safety and Care Advice

Product Details

Larsa Dining Table Black / 4728993 Larsa Dining Table Red / 5794287

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- This product has been constructed to be used in the domestic environment only and not for commercial purposes.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.



• We do not recommend the use of power drill/drivers for inserting screws

as this could damage the unit. Only use hand screwdrivers.

- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.
- Use a dry cloth to clean the product, furniture polish is not recommended.
- From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Additional Guidance

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightend properly.
- Maximum loading weight 100kg
- This product is compliant EN12521

Fittings (Shown to scale)


Bag 1



Panels



1 Top Panel x1 (1700 x 850mm)



Side Leg frame x2 (740x 720mm)



Support frame x2 (1270x 490mm)

