
Slim Bamboo Clothes Rail

Assembly Instructions - please keep for future reference

473/8639



Dimensions

Width - 45cm Depth - 45cm Height - 148cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on page 2

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.

• We do not recommend the use of power drill/drivers for inserting screws, as this could damage

the using. Only use hand screwdrivers

Care and maintenance


• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners. • From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts • Regularly check and ensure that all bolts and fittings are tightend properly.

Components - Panels






Components - Fittings

If you have damaged or missing components, call the Customer Helpline: 0345 640 0800

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions

Step 1

1. Into the ends of 2 x Short support rail 3 and 2 x Long support rail 4 insert 8 x Dowels F

Step 2

 Connect 2 x Upright Bars 1 together using 1 x Short Support Bar 3 and 1 x Long Support Bar
 Locate dowels within each one into holes shown. Using Allen key A insert 4 x Screw B

2. Connect the top of the bars together using
1 x Screw D,
1 x screw and
2 x Female Threaded
Boss C as shown


Repeat for remaing upright bars 1

Step 3


1. Connect top rail 2 to Bars 1 with 1 x Screw B using Allen key A

2. Connect Top rack
5 to Uprights 1 with 2
x Screw B using Allen key A

3. Connect Bottom Rack 6 to Uprights 1 with 2 x Screw B using Allen Key A



Assembly Instructions



If you need help or have damaged or missing parts, call the **Customer Helpline: 0345 640 0800** Argos LTD. 489-499 Avebury boulevard, Central Milton Keynes, MK9 2NW