


# Wow Oslo Dining Chair

Assembly Instructions - Please keep for future reference

482/2844

482/7014

**H O**  
**M E**  
**BY ARGOS**



## Dimensions

Width - 40.5cm

Depth - 47cm

Height - 91cm

**Important - Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, call the **Customer Helpline:**  
**Argos = 0345 640 0800**



# Safety and Care Advice

**Important** - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- Unit weight: 3.72 kgs.
- Maximum safe weight of user: 110kgs.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.

- Do not stand on the chair.
- Do not use this chair as step ladder.
- This product should not be discarded with household

waste. Take to your local authority waste disposal centre.

## Handy Hints


- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightend properly.

# Components - Parts


If you have damaged or missing components, call the  
Customer Helpline: Argos = 0345 640 0800

Please check you have all the parts listed below

**Note:** The quantities below are the correct amount to complete the assembly of 1 chair.



**1** Backrest  
(40.5 x 91 x 7cm)




**2** Leg Frame x 2  
(41.5 x 41.5 x 1.9cm)



**3** Seat Rail  
(35.5 x 1.3 x 1.3cm)



**4** Front Rail  
(35 x ø1.3cm)




**5** Seat  
(40 x 40 x 5cm)


# Components - Fittings

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly of 1 chair.



M6 x 35mm Bolt x 8




M6 x 25mm Bolt x 4



Allen Key x 1

**Ruler** - Use this ruler to help correctly identify the screws





# Assembly Instructions

## Step 1

### Attaching leg frames

Position the leg frames **2** on the backrest **1** as shown and fix through holes using bolts **A**.

Tighten bolts using allen key **C**.





## Step 2

### Attaching rails

Position the seat rail **3** between the leg frames **2** as shown and fix through holes using bolts **A**.

Tighten bolts using allen key **C**.

**Repeat above step to assemble the front rail **4** on the leg frames.**



# Assembly Instructions



## Step 3

### Attaching seat


Place the seat **5** on a raised protected surface.

Position the assembled chair frame on the seat as shown and fix through holes on the leg frames **2** using bolts **B**.

Tighten bolts using allen key **C**.



Carefully turn over the chair and place on a firm surface.



**Assembly is complete.**

If you need help or have damaged or missing parts, call the **Customer Helpline:**  
**Argos = 0345 640 0800**