

Maintenance


This fitting is designed for indoor use only.
Do not use polish or abrasive cleaner - just a soft dry cloth.

BULB REPLACEMENT

- 1. Switch off the mains power supply.
- 2. Before replacing the bulb, allow it to cool down for at least 10 minutes.
- 3. Never touch the bulb with your fingers directly, cover it with a cloth.
- 4. Loosen the bulb and remove it from the lamp.
- 5. Replace a new bulb with same voltage and wattage (Max.5W LED G9, bulb not included)

Recycling electrical products

You should now recycle your waste electrical goods and in doing so help the environment. This symbol means an electrical product should not be disposed of with normal household waste. Please ensure it is taken to a suitable facility for disposal.
Visit www.recycle-more.co.uk, click on “bank locator” and enter your postcode to find your nearest recycling site.




If you require any further assistance, you can contact us on **0345 640 2020** or visit **habitat.co.uk/help/contact-us**

Made in China
Habitat, Argos Limited, London, EC1M 6HA, UK.
Argos (N.I.) Ltd. Forestside Shopping Centre,
Upper Galwally, Belfast, BT8 6FX, UK.



HABxM&C library swing arm floor lamp

4844389



Care & Instruction Manual

For household and indoor use only

Please read and retain these instructions for future reference

Important

- Read these instructions carefully and familiarize yourself with the procedure before assembling the unit.
- Ensure you have enough space to lay out all the parts before assembly.
- Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated.
- To avoid scratching it is recommended that you assemble the unit on a soft level surface.
- When changing the bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.
- This luminaire is Class II insulated.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- The luminaire is designed for indoor use only.

Instruction for use

1. Assemble the bottom tube onto the top section. Ensure the excess cable does not become trapped or twisted when fixing together. Then pull surplus cable through the bottom tube.
2. Remove the screw nut, washer and shim plate under the bottom tube then attach the base onto it and secure in place with the shim plate, washer and screw nut by using the spanner supplied.
3. Undo the fastener to adjust to the pole height of choice and tighten to secure. (NOTE: To prevent any scratches on the pole, please avoid unscrewing the stem holder completely.)
4. Fit the bulb: Type and wattage as indicated on the fitting. The wattage indicated must not be exceeded.

