

Maintenance


This fitting is designed for indoor use only.
Do not use polish or abrasive cleaner - just a soft dry cloth.

BULB REPLACEMENT

- 1. Ensure the lamp is disconnected from mains.
- 2. Remove the metal cap,plastic seal ring and glass shade from the metal frame.
- 3. Before replacing the bulb, allow it to cool down for at least 10 minutes.
- 4. Never touch the bulb with your fingers directly, cover it with a cloth.
- 5. Loosen the bulb and remove it from the lamp.
- 6. Replace a new bulb with same voltage and wattage (**Max.10W LED E14, bulb not included**)
- 7. Attach the glass shade onto the metal frame and secure in place with the plastic seal ring and metal cap.
- 8. Plug the lamp into a suitable mains socket.

Recycling electrical products

You should now recycle your waste electrical goods and in doing so help the environment. This symbol means an electrical product should not be disposed of with normal household waste. Please ensure it is taken to a suitable facility for disposal.
Visit www.recycle-more.co.uk, click on “bank locator” and enter your postcode to find your nearest recycling site.




If you require any further assistance, you can contact us on 0345 640 2020 or visit habitat.co.uk/help/contact-us	Made in China Habitat, Argos Limited, London, EC1M 6HA, UK. <u>Argos (N.I.) Ltd.</u> Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.
---	---



HABxM&C cloche touch table lamp

4847025



Care & Instruction Manual

For household and indoor use only

Please read and retain these instructions for future reference

Important

- Read these instructions carefully and familiarize yourself with the procedure before assembling the unit.
- Ensure you have enough space to lay out all the parts before assembly.
- Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated.
- To avoid scratching it is recommended that you assemble the unit on a soft level surface.
- When changing the bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.
- This luminaire is Class II insulated.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- The luminaire is designed for indoor use only.
- This product does not have a dimmer function and is not compatible with dimmable light bulbs.

Instruction for use

1. Ensure the lamp is disconnected from mains.
2. Fit the bulb: Type and wattage as indicated on the fitting. The wattage indicated must not be exceeded.
3. Remove the metal cap and plastic seal ring from the top of metal frame, then attach the shade onto it and secure in place with the plastic seal ring and metal cap.
4. Plug the lamp into a suitable mains socket.
5. Touch the lampbody to switch on and off.

