


# Moda Regular Sofa

Assembly Instructions - Please keep for future reference

460/5061  
497/4761  
483/6270  
461/9394  
457/7577  
482/9995  
473/9391  
453/5423  
717/6494  
703/7825



## Dimension

Width - 177cm  
Length - 83cm  
Height - 64.5cm

**Important - Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, call the **Customer Helpline: Argos = 0345 601 2895**



# Safety and Care Advice

## Important - Please read these instructions fully before starting assembly

- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

# Components - Fittings

## Please check you have all the fittings listed below

**Note:** the quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.




# Assembly instructions

## Step 1

### Attaching legs

Insert Leg **A** into armrest and rotate to right.

Repeat this operation for all 4 legs.



Assembly is now complete.

**Note:** if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.