DAXTON. 3 LEVEL SHOE STORAGE


Assembly Instructions - Please keep for future reference

DAXT-3SS-AW20-A

Dimensions

Width -50cm Depth -17cm Height -106cm

Tools required







WARNING! This product contains small magnets that can be hazardous if swallowed. Please check them periodically to ensure they are secure.

Seek immediate medical attention if magnet(s) are swallowed or inhaled.

Important – Please read these instructions before assembly

If you need help or have damaged or missing parts, email: customerservices@habitat.co.uk or call: 0344 499 4686 habitat®

Important – Please read these instructions fully before starting assembly

General care and maintenance

Dust regularly with a clean dry cloth.

Wipe up any spills immediately with a damp cloth and then dry the surface with a clean dry duster.

Repeat this procedure for periodic cleaning.

The use of furniture polish or spray is not necessary or recommended.

From time to time check that there are no loose screws on this unit.

This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Important! Fixing your shoe storage to the wall


For stability your Daxton Shoe Storage unit must be attached to a wall. Always remember to use screws and fixings appropriate to your wall type - please refer to the Wall Mountings and Fixings Guide on the last page of this instruction for more information.

This unit comes with pre-made screw holes on the back panel. These fixing holes can be easily accessed by opening the top drawer of the unit.


General information

If for any reason you should have problems with your Habitat product, please contact the store from which you purchased it. Please retain your receipt as proof of purchase.

If you have any comments or suggestions regarding this product, assembly instructions or service received, please contact the store or Habitat Head Office via its web site: www.habitat.co.uk or write directly to: Habitat Retail Ltd. 489-499 Avebury Boulevard, Milton Keynes MK9 2NW



Fitting wall Strap



A Guide to - Wall Mounting & Fixings

Important note:

Wall Fixings:



- because of the variety of different wall types, Habitat cannot provide you with the exact fixings you will need to fix this product to the wall.

You must first identify the type of wall you intend to fix product onto and then contact your local hardware store to get the appropriate fixings.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.


Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

- **1: General rule:** Always use a larger screw and wall plug if you are not sure.
- **2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- **3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- **4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- **5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.


Types of walls

No.1 "General Purpose" wall plug



Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.




You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.3 "Cavity Fixing" wall plug



For use with plasterboard partitions or hollow wooden doors.


No.4 "Cavity Fixing-Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.


Safety: Always check the fitting and location to ensure your safety in and around the home.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.