
This product is suitable for children AGE 3-12 YEARS

RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCES. ASSEMBLY TO BE CARRIED OUT BY A COMPETENT ADULT ONLY.

Full assembly instructions including a list of components and tools required.




TOOLS REQUIRED

Allen Key (Supplied)


STEP BY STEP ASSEMBLY

Attention: Do no tighten the screws until you have completed assembly.

Please note: You may notice the top panel of this unit has a join were the edging material is fixed/glued. When assembling the top of the unit you may want to ensure that this join is at the back of the unit (towards the wall - rather than the front). This may just be slightly more pleasing to the eye.



STEP BY STEP ASSEMBLY



CARE AND MAINTENANCE INSTRUCTIONS

- Wipe furniture with a soft dry cloth, do not use paper as this may be abrasive to the finish.
- The unit should be cleaned with a damp cloth and dried with a dry cloth.
- DO NOT use bleach or chemical solutions to clean the product.
- DO NOT expose to sunlight or other heat sources for a prolonged period.
- DO NOT store or leave outside.
- · Periodically check the tightening of legs and screws.

SAFETY TESTED

The product conforms to:

FIRA FRQG C001:2021 / FIRA FRQG C004:2016+A1:2017

WARNINGS

- 1. WARNING: Serious or fatal crush injuries can occur from furniture tip over. ALWAYS secure this unit to wall with wall fixings supplied.
- 2. WARNING: DO NOT use this product if any part is broken, torn or missing. Please contact your supplier and spare parts can be supplied please use only parts approved by the manufacturer.
- 3. Please keep children away from the work area during assembly of this product due to risk of injury.
- Please keep children away from the work area during assembly of this product due to small parts.
- 5. Once assembled, this product is NOT designed to be dismantled, transported and reassembled.
- 6. Dispose of all packaging carefully and responsibly.
- 7. We advise you to keep these instructions in a safe place in case required for future use.
- 8. Assembly to be carried out by a competent adult only.
- 9. Do not use this item if any components are missing or damaged.
- 10. This product is suitable for children in the age range 3-12 year old.
- 11. The maximum loading weight of the product is 75 KG.
- 12. Regular check all fastenings to ensure that they are properly tightened.



