Amelia Breakfast Set

Assembly Instructions - Please keep for future reference

600/5573

600/2284



Dimensions - Table

Width - 115cm

Depth - 40cm

Height - 93cm

Dimensions - Chair (x2)

Width - 36cm

Depth - 41cm

Height - 85.5cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0845 640 0800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on this product during assmebly, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor .
- Parts of the assembly will be easier with 2 people .



• We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit.
Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels

Please check you have all the panels listed below



1 Top (115 x 40cm)




2 Outer support (36 x 91.5cm)

5 Large tray (55.6 x 34cm)



3 Middle support (36 x 91.5cm)





6 Wine rack (35.5 x 34cm)






7 Small tray x 2 (35.5 x 34cm)

Components - Fittings If you have damaged or missing components, call the Customer Helpline: 0845 640 0800

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Tools required



Ruler - Use this ruler to help correctly identify the screws


5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170 hadaalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataal

Assembly Instructions

Step 1

Attaching angle plate

Attach angle plate **5** to top **1** with screw **6**.




Step 2

Attaching sides & leg

Attach outer support 2, middle support 3 and leg 4 to top 1 with bolts A using hexagonal key D.

Do not over tighten bolts.



Assembly Instructions


Step 3

Attaching racks

Attach large tray 5 to leg 4 and middle support 3 with bolts B and C using hexagonal key D.

b: Attach wine rack 6 and small tray 7 to outer support 2 and middle support 3 with bolts B using hexagonal key D.

Tighten all the bolts.



Assembly Instructions

Step 4

Attaching to wall


It is recommended that the unit is fixed to a wall.

Mark fixing hole on wall and remove the unit. Wall screws are not supplied.



Warning: Before drilling, check wall for hidden pipes and cables.

Assembly is complete.



Note: The correct type of fixing must be used for your wall, seek professional advice if in doubt.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800** Argos Ltd MK9 2NW