

Amelia Breakfast Set

Assembly Instructions - Please keep for future reference

600/5573

600/2284



Dimensions - Table

Width - 115cm
Depth - 40cm
Height - 93cm

Dimensions - Chair (x2)

Width - 36cm
Depth - 41cm
Height - 85.5cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3 .
- Remove all fittings from the plastic bags and separate them into their groups .
- Keep children and animals away from the work area, small parts could choke if swallowed .
- Make sure you have enough space to layout the parts before starting .

- Do not stand or put weight on the product, this could cause damage .
- Assemble the item as close to its final position (in the same room) as possible .
- Assemble on a soft level surface to avoid damaging the unit or your floor .
- Parts of the assembly will be easier with 2 people .



• We do not recommend the use of power drill/drivers **for inserting screws** , as this could damage the unit . Only use hand screwdrivers .


- Dispose of all packaging carefully and responsibly .

Care and maintenance


- Only clean using a damp cloth and mild detergent , do no use bleach or abrasive cleaners .
- From time to time check that there are no loose screws on this unit .
- This product should not be discarded with household waste . Take to your local authority waste disposal centre .

Components - Panels


Please check you have all the panels listed below



1 Top (115 x 40cm)




2 Outer support (36 x 91.5cm)




3 Middle support (36 x 91.5cm)




4 Leg (Ø3.8 x 91.5cm)



5 Large tray (55.6 x 34cm)



6 Wine rack (35.5 x 34cm)







7 Small tray x 2 (35.5 x 34cm)

Components - Fittings

If you have damaged or missing components,
call the **Customer Helpline: 0845 640 0800**

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  10mm Bolt x 8	B  48mm Bolt x 14	C  30mm Bolt x 1
D  4mm Hexagonal key x 1	E  12mm Screw x 2	F  Angle plate x 2

Tools required



Phillips screwdriver
(medium)



Ruler/tape
measure

Ruler - Use this ruler to help correctly identify the screws





Assembly Instructions

Step 1

Attaching angle plate

Attach angle plate **F** to top **1** with screw **E**.





Step 2

Attaching sides & leg

Attach outer support **2**, middle support **3** and leg **4** to top **1** with bolts **A** using hexagonal key **D**.

Do not over tighten bolts.




Assembly Instructions

Step 3

Attaching racks


a: Attach large tray **5** to leg **4** and middle support **3** with bolts **B** and **C** using hexagonal key **D**.

a:



b: Attach wine rack **6** and small tray **7** to outer support **2** and middle support **3** with bolts **B** using hexagonal key **D**.

b:



Tighten all the bolts.

Assembly Instructions

Step 4

Attaching to wall



It is recommended that the unit is fixed to a wall.

Mark fixing hole on wall and remove the unit. Wall screws are not supplied.



Warning: Before drilling, check wall for hidden pipes and cables.

Assembly is complete.



Note: The correct type of fixing must be used for your wall, seek professional advice if in doubt.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**
Argos Ltd MK9 2NW