


Suki TV Unit

Assembly Instructions - Please keep for future reference

609/7426



Dimensions

Width - 92cm

Depth - 37cm

Height - 43cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not use this item if any components are missing or damaged.

- Do not stand on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.
- **Note:** Only apply the glue once you are sure of the assembly.

Glue safety - Take care when using glue, please follow the advice below

Skin contact: Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.

If swallowed: Seek medical advice immediately.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800**


Please check you have all the panels listed below



1 Top panel (91.6 x 36.8cm)




2 Bottom panel (91.6 x 36.8cm)




3 Middle right panel (36.7 x 38.6cm)

4 Middle left panel (36.7 x 38.6cm)




5 Right side panel (14.7 x 38.6cm)

6 Left side panel (14.7 x 38.6cm)




7 Right shelf (17.7 x 14.5cm)

8 Left shelf (17.7 x 14.5cm)



9 Middle shelf x 2 (49.6 x 36.6cm)





10 Back panel x 2 (19.2 x 38.6cm)




Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. in some cases more fittings may be supplied than are required.

A  30mm Dowel x 8	B  50mm Screw x 18	C  Foot x 4
D  39mm Locking pin x 6	E  Nail x 6	F  15mm Locking nut x 6
G  Glue x 1		


Tools required



Phillips screwdriver
(medium & large)



Flatblade screwdriver
(medium)



Small
hammer




Ruler/tape
measure



Eye protection
(when using a
hammer or glue)

Ruler - Use this ruler to help correctly identify the screws





Assembly Instructions

Step 1

Fitting dowels



a: Insert Dowels **A** into the Middle right panel **3** and Middle left panel **4**.

a:



b: Insert Dowels **A** into the Right shelf **7** and Left shelf **8**.

b:




Assembly Instructions

Step 2

Attaching left and right shelves


a: Use Screws **B** to fix Middle left panel **4** onto the Left shelf **8**.

a:



b: Use Screws **B** to fix Middle right panel **3** onto the Right shelf **7**.

b:




Assembly Instructions

Step 3

Attaching middle shelves


a: Use Screws **B** to fix Middle shelves **9** onto the unit.

a:



b: Use Screws **B** to fix Middle right panel **3** onto the unit.

b:




Assembly Instructions

Step 4

Attaching side panels


a: Position Left side panel **6** onto the unit.

a:



b: Position Right side panel **5** onto the unit.

b:




Assembly Instructions

Step 5

Attaching bottom panel


Use Screws **B** to fix Feet **C** onto the unit.



Step 6

Inserting back panels

a: Place a small amount of Glue **G** into the grooves of Middle right panel **3** and Middle left panel **4**.



Continued on next page.

Assembly Instructions


Step 7 - continued

b: Position Top panel **1** onto the unit.

Insert 6 Locking nuts **F** into the unit.

Use a screwdriver to turn Locking nuts **F** clockwise to lock.

b:




Step 8

Fixing back panels

Attach Back panels **10** onto the unit using Nails **E**.



Important:
The unit **MUST** be 'square' when back is attached.



Assembly Instructions


Step 9

Finishing the unit

Note: It would be useful to ask someone to help you at the stage.

With help, place the unit in the intended position.

Note: Before use allow the glue to dry for 24 hours and make sure the unit is secure.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**