

Cast Aluminum Round 70cm Table

Assembly Instructions - Please keep for future reference

650/3037



Dimensions

Width - 70cm
Depth - 70cm
Height - 69cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400 800

For further assistance please visit <http://www.argos-support.co.uk/>



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble on a soft level surface to avoid damaging the unit or your floor.

- Assemble the unit as close to its final position (in the same room) as possible.

- Parts of the assembly will be easier with 2 people.

- If using power tools, please follow the safety instructions supplied with the tools.



- We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.

- Warning: The unit weights approximately 5 kgs.

Please lift with care.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- Suggestion: When you do not use it, find one suitable cover on it.

- From time to time check that there are no loose screws on this unit.

- Don't fully tighten all screws until assembly is complete.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


- Make sure each screw matches the corresponding figure to ensure correct assembly.

Components - Parts


If you have damaged or missing components,
call the Customer Helpline: 03456 400 800
For further assistance please visit <http://www.argos-support.co.uk/>

Please check you have all the parts listed below


1 1 x Table Top



2 1 x Leg Support











3 4 x Leg



Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

 A 4 x Stud M6x32	 B 4 x Nut	 C 4 x Spring Washer
 D 4 x Washer	 E 8 x Small stud M6x28	 F 8 x Small Nut
 G 8 x Small Spring Washer	 H 8 x Small Washer	

Tools required



1xWrench



Not included

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Fix the studs **A** into the table top **1** then fit the legs **3** over the studs fitting on the Table Top **1**. Use Nuts **B**, Spring Washers **C** and washers **D** to fix the legs **3** onto the Table Top **1**.

See fig. 1.

NOTE: Do not tighten screws until completely assembled





Step 2

Fix the studs **E** to the leg support **2** first
See fig. 2.

Use studs **E**, nuts **F**, spring washers **G** and washers **H** to fix leg support **2** onto the legs.
See fig. 3.

Tighten all the screws.




Assembly Instructions

Step 3

Carefully turn the unit upright. Then place the unit in the desired location.
See fig. 3.

The rubber screw caps at bottom of the four legs can be adjusted.
If necessary, to make the legs level with the ground.

Assembly is complete



If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400 800

For further assistance please visit <http://www.argos-support.co.uk/>

Retailer: Argos

Address: 489-499 Avebury Boulevard Saxon Gate West. Central Milton Keynes Bucks. MK9. 2NW