

Get started in 2 minutes!

We know you'll want to start NutriBlasting right away, so we've compiled a few top tips to help you get started. But remember; it's important to **fully read the manual** before starting your journey to get the absolute best out of your brand new NutriBullet!



Find us..

 channels: 666-667-668-672-675

 highstreettv.com

 high street tv

It's thirsty work!

Remember to **always** add **cold liquid** (water, juice, milk...) to your NutriBlast, before blasting. Never use warm, hot or carbonated liquid, and always stay within the max line!



Keep it together

When you're ready for blast-off, double check you've **securely tightened** the blade on the cup first so nothing leaks out!



Short and sweet

For great results, blast in 20 second bursts, and **never longer than 1 minute** at a time. This will help to keep your NutriBullet in tip top condition.



20 secs



Patience makes perfect

Always wait until the blades and motor come to a **complete stop** before removing your cup from the base to prevent damage to the motor.



Don't leave me this way!

When done, always remove the blade from the cup to release pressure, even if you've created a NutriBlast to enjoy later. This will prevent fermentation of the fruit within the cup. If you find the blade difficult to remove, use a tea towel and firmly twist.



Spick and span

Simply rinse the cup and blade under the tap for super quick clean-up. All other parts (apart from the motor base and blades) are dishwasher safe too. To keep your NutriBullet ship shape, regularly unplug the base and give the inside of the motor area a quick wipe with a damp cloth or bristle brush for tough to reach areas.



A match made in NutriBullet® heaven

We have so many fantastic accessories to compliment your NutriBullet that we know you'll love, including:

- NutriBullet Deluxe Upgrade Kit
- NutriBullet Blast Off Bag
- Hardback Recipe Book
- Replacement blades

To order, call: 0344 800 0837

Or why not have a browse online at www.buynutribullet.co.uk



Check out our short videos for tips, tricks and how to get started!

Visit the High Street TV channel on YouTube



Register Your Product

We'd love to keep in touch with you!

Simply register your product at highstreettv.com/registration for:

- Latest product information
- Specialist after care service
- Exclusive special offers

Any Concerns?

Ask yourself, do you really want to return your new NutriBullet? If the answer is yes, please check:

- Was your order received less than 30 days ago?
- Is your NutriBullet unused (no leftover NutriBlasts please), in a re-sellable condition, and with original packaging including all instructions, contents, and any free/bonus items received with your order?

If yes, contact your retailer, or visit highstreettv.com/returns for orders purchased directly from us.




NUTRIBULLET.
600 SERIES

Share the Nutri Love

 /OfficialNutriBulletUK

 @nutribulletuk

 @NutriBulletUK

 Search High Street TV