




7045082 Brushed Stainless Steel Sensor Bin 50L



Please read carefully before using.

1. Open the battery cover insert/ replace the new batteries in the proper direction indicated inside the battery compartment. 	2. Press switch to "I" position and after 3 seconds the sensor function will start to work. 
3. Remove the ring form the top of the bin. Place the bin bag through the ring and place any access bag inside the bin and replace the ring back on top of the bin. 	4.If you forget to touch the "Close ". The lid will close automatically after 15 minutes. 
5. After the hand is moved away from the sensor area the lid will close after 5 seconds. 	6. When the indicator light turns to red this indicates that the batteries will need replacing in one week. 

Cautions:

1. Battery: 1.5V x 4 AA battery.
2. Keep in a dry environment.
3. If the lid battery case accidentally be flooded, please take out the battery immediately, put the whole lid in a dry place. Make sure the lid is dry before reuse.
4. Please change the new batteries in time after used batteries run off.
5. Match corresponding batteries in low-temperature environments.
6. The lid cannot be forced on by hand, which will damage the switching electronics.
7. It is best to stay away from refrigerator, induction cooker and other high frequency electromagnetic radiation products, those may interfere with the induction function of the sensor function.
8. Indoor used only, the bright light can cause the damage of sensor.
9. Make sure there is no cover up to 70 centimeters above the sensing area.

Warnings

BATTERY SAFETY

- Batteries should be installed by an adult.
 - Never mix old and new batteries (replace all batteries at the same time)
 - Never mix alkaline standard (Carbon Zinc) or rechargeable batteries
 - Do not recharge non-rechargeable batteries.
 - Rechargeable batteries must be removed before recharging and charged under adult supervision.
 - Remove batteries from product before extended storage or if exhausted.
 - Never try to dismantle batteries
 - Do not short circuit the supply terminals.
- Batteries may explode or leak if misused.
 - Do not dispose of batteries in a fire.
 - Please retain this information for future reference

Recycling electrical products:

You should now recycle your waste electrical goods and in doing so help the environment. This symbol means an electrical product should not be disposed of with normal household waste. Please ensure it is taken to a suitable facility for disposal. Visit www.recycle-more.co.uk click on “bank locator” and enter your postcode to find your nearest recycling site.

