

TIKKERS_S34_0021 BLUE


DESIGNER
S FROGGATT

ISSUE DATE
13/05/2024

FACTORY
GELITE

DIMENSIONS
H- 120MM
W- 80MM

FOILS / SPECIAL FINISHES
SPOT UV GLOSS & FOIL DETAILS



Peers Hardy Group

HOW TO CARE FOR YOUR SMART WATCH

Do not wear your smart watch whilst applying sprays or creams. Do not allow contact with any corrosive agent e.g. paint, solvents or adhesives, as this may affect the finish of the smart watch. Do not try to replace or disassemble the battery.

SILICONE STRAP CARE

To keep your silicone strap looking good, clean it regularly with mild soap and water to remove any dirt, oils, lotions etc., ensuring the case of your smart watch does not get wet. When you are not wearing your smart watch, we recommend you store it in the gift box received with purchase.

STEP COUNTER

Smart watches use multiaxis inertial sensors called accelerometers. These detect wrist movement in order to measure steps. However, some wrist actions whilst standing or sitting can mimic the arm movement of a step and can therefore falsely record steps. The step count recorded each day should be used as a guide only.

IP68

Your watch is IP68 and it is certified suitable to be submerged for up to 30 minutes to a maximum depth of 1.5 Meters.

We do not recommend our watches for use in saltwater. Always rinse and dry your smart watch after use.

GUARANTEE

Quality and style are at the heart of what we do. Tikkers certifies this product is produced using premium materials and is fully tested before leaving our manufacturing centre.

Your product is guaranteed against any defective parts & construction for 2 years from the date of purchase. Your guarantee is only valid if you present your original receipt when returning the item. This guarantee provides you with rights in addition to your consumer statutory rights and therefore does not limit your statutory rights. Please note this guarantee does not cover lenses, bands, straps or bracelets, water penetration or batteries. Additionally, breakages caused by accident or maltreatment are not covered.

We hope you'll love your watch, but if you do have any problems please contact us and we'll guide you through the guarantee process.

+44 (0) 121 524 1400 tikkers.co.uk

COMPATIBILITY

The Tikkers App. is compatible on the following smart phones:

Android (version 8.0 and above)

Apple iOS (version 12.0 and above)

Please make sure the App. is the latest version and check for updates.

Bluetooth requirement 5.0. Bluetooth Range 10m

PRIVACY POLICY - tikkers.co.uk/pages/privacy-policy

SMART WATCH SAFETY & WARNINGS

TIKKERS smart watches contain components that emit electromagnetic fields, with some of the models containing a magnetic charging dock, please be aware that these models contain magnets. These electromagnetic fields and magnets may interfere with medical devices, such as pacemakers and implanted defibrillators. Please consult your doctor and medical device manufacturer if you use any medical device before using a TIKKERS smart watch. The TIKKERS heart rate monitor is designed for recreational use only, it is not intended for any medical use such as diagnosing or monitoring any medical conditions. The TIKKERS heart rate monitor usually provides an accurate estimate of your heart rate, but the reading can be affected by factors such as fit of the smart watch, the physical characteristics of the wearer and the intensity of the activity. Your TIKKERS smart watch will help calculate distances covered. Please consult a doctor before starting new exercise regimes. TIKKERS smart watches contain sensors to track your movement to closely estimate your activity, sleep etc. These close estimations are not always fully accurate. Some wearers may suffer skin irritation if the smart watch is worn for prolonged periods, especially if you suffer from sensitive skin or have allergies. If you notice any irritation you should remove your smart watch. To help prevent any irritation please ensure the smart watch is removed regularly for cleaning & do not over-tighten on your wrist. We recommend you remove your smart watch each day for gentle cleaning.

BATTERY WARNINGS

Do not attempt to replace the battery, open the device enclosure or disassemble your TIKKERS product. Doing so can result in a safety hazard. The integrated rechargeable battery cannot be removed or replaced. Substances within TIKKERS smart watch batteries may harm the environment or cause injury if handled or disposed of improperly. In the unlikely event of contact with battery acid, thoroughly flush the affected area with plenty of clean water and seek IMMEDIATE medical attention. When the battery is fully charged disconnect from charger. Please take care to not overcharge.

DEVICE WARNINGS

This smart watch is a Class A product. In a domestic environment, this product may cause radio interference. In which case the user may be required to take adequate measures. Ensure your smart watch correctly engages with the charging contacts. Before each use, please check the product for damage, do not use if the product is damaged. This is not a toy, children should not play with this product. Never attempt to open your smart watch, this may result in danger. Protect the product from strong impacts, vibrations, direct sunlight and dirt. Do not place heavy objects on the product. Do not exert pressure on the product. Avoid strong magnetic fields e.g. loudspeakers. Salt and thermal water can lead to the corrosion of metal parts. Remove the product before using sounds as the temperature difference can cause condensation. Do not operate the product near heat sources e.g. radiators or other devices emitting heat. Do not cover the product during operation or charging. Never use the product on aeroplanes, in hospitals, service rooms, or near medical electronic systems. The wireless signals transmitted could impact the functionality of sensitive electronics. Do not use your TIKKERS product if the display is cracked. Do not expose your TIKKERS product to extremely high or low temperatures. Do not use abrasive cleaners to clean your TIKKERS product. Remove your TIKKERS product immediately if it feels warm or hot. Do not attempt to wear or operate your TIKKERS product whilst charging. Do not charge your TIKKERS product if wet. Do not check notifications or other applications on the products display while driving or in other situations where distractions could be hazardous. Always be aware of your surroundings when using TIKKERS products and services. Ensure your smart watch is removed at regular intervals for gentle cleaning.

In the case of material damage or personal injury caused by incorrect handling or non-compliance with the safety instructions, no liability can be accepted by TIKKERS. If you have any questions or concerns, please contact us, you'll find our contact details on this leaflet.

Manufactured by: Peers Hardy UK Ltd, Precision House, Starley Way, Birmingham Business Park, Bickenhill Lane, Solihull, B37 7GN, UK. EU Address, Peers Hardy UK LTD, C/O Global E-commerce Experts, Rijnlanderweg 766, Unit H, 2132 NM, Hoofddorp, Netherlands. Made in China.

Please retain this leaflet for future reference.

TIKKERS

SMART WATCH
QUICK START GUIDE

TIKKERS.CO.UK

TIKKERS.OFFICIAL
 TIKKERS.OFFICIAL
 TIKKERSOFFICIAL

6+ CE UK CA

TIKKERS



THANK YOU FOR CHOOSING A TIKKERS SMART WATCH! THIS SHORT GUIDE WILL HELP YOU WITH THE ESSENTIALS, BUT PLEASE VISIT OUR WEBSITE TO ACCESS FULL INSTRUCTIONS, HELPFUL VIDEOS, FAQS AND MORE, ALL DESIGNED TO HELP YOU GET THE BEST FROM YOUR TIKKERS PRODUCT.

SCAN THE QR CODE BELOW TO GO STRAIGHT THERE, OR NAVIGATE TO THE SUPPORT SECTION FROM OUR HOME PAGE.



TIKKERS.CO.UK

DON'T FORGET TO FOLLOW US ON SOCIAL MEDIA FOR LOTS OF FUN STUFF! WE'D LOVE YOU TO TAG US IN YOUR PHOTOS SHOWING YOUR NEW TIKKERS™ PRODUCTS!

JOIN THE TEAM ON SOCIAL!

TIKKERS.OFFICIAL
 TIKKERS.OFFICIAL
 TIKKERSOFFICIAL

LETS GET STARTED!

INSTALL TIKKERS APP.

Search for Tikkers App to download onto your smart phone. Alternatively, you can scan the QR code below.



SMART WATCH INSTRUCTIONS

CHARGING GUIDE

Line up the 2 pins to the charging spots on the back of the watch case. The pins are magnetic and will secure the charger in place. Plug the USB cable to a power source. Once connected, the charging icon will appear on screen. Charge the watch when it displays low battery. A 2 hour charge time is sufficient to fully charge your smart watch, please take care to not overcharge.

POWER ON/OFF

To switch on and off, press and hold the crown until display illuminates. Alternatively, swipe down on the dial screen and select settings and find the option power off or restart.

DIALS

To switch between the dials press and hold the screen and swipe left or right to view. Once you have selected your dial tap to set. You can also select a photo from your smartwatch gallery to use as a dial. Tap the watch face settings within the app. Tap edit on a watch face. Select a photo you'd like to use. Move and scale within the guide.



HEART RATE

View your current heart rate. Your smartwatch will continue to detect your heart rate as long as you wear it even when you sleep! Note: Settings can be changed within the app.

ACTIVITY TRACKING

This feature helps you keep a track of all sports you have tracked with the smartwatch. Your exercise is recorded in the app. Note: If your activity time is less than 5 minutes, the data will not be saved.

SLEEP

Wear the watch to fall asleep and it will record your sleep data of the last night on the next day. Note: Sleep detection starts from 9pm to 8am the next day and will update data by midday.

MESSAGES

Unread messages will be displayed in notifications. Press the screen to enter and read the messages on the watch.

WEATHER

After connecting to the app, you can select the city and the weather for this city will be displayed on your smartwatch.

DRINK ALERTS

Hydration is key to feeling your best, your watch will remind you it's time to take a drink. You can set the feature in the app.

ACTIVITY REMINDER

Turn on the sedentary reminder and set in the app. Your watch will vibrate to remind you to take a little exercise. Note: Settings can be changed within the app.

MUSIC CONTROL

When listening to music wireless connection on your phone you can control the music on the watch interface.

STEP CONTROL

The band will record your daily activity automatically.

CALL ALERTS

After connecting to the app, turn on notifications in phone settings and you will receive call notifications and press to reject the call on your smartwatch.

CAMERA CONTROL

Once connected to the app, the photo feature will be accessible via settings. You can take a photo on your camera phone by pressing the option on your watch. The phone needs to be unlocked for it to work.

FIND YOUR PHONE

Once the smartwatch is connected to the app, the find phone feature will be available. Open the find your phone option on your smartwatch and your phone will sound a locator alarm.

ALARM

Set alarms on your watch.

STOPWATCH

Time anything with the stopwatch feature on the watch.

Brightness

Other settings within the watch include brightness, reset, about and shut down.

Reset

About

Shutdown