
Clothes Rail

Assembly Instructions - please keep for future reference

806/9407



Dimensions

Width - 63.5cm Depth - 40cm

Height - 164cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on page 2
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 We do not recommend the use of power drill/drivers for inserting screws, as this could damage

the using. Only use hand screwdrivers

Care and maintenance


- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste.
 Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightend properly.

Components - Panels

Please check you have all the panels listed below




Components - Fittings Call the Customer Helpline: 0345 640 0800


If you have damaged or missing components,

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Tools required



Ruler – Use this ruler to help correctly identify the screws

45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions

Step 1

- 1. Connect Uprights Bars

 1 and 2 as shown
 using 2 x Screws A
 and 2 x Female
 Threaded boss B
 as shown
- 2. Connect Uprights Bars


 3 and 4 as shown
 using 2 x Screws A
 and 2 x Female
 Threaded boss B
 as shown

Step 2

1. Into Front Bar 6 insert 4 x Dowels **D**

Step 3

- 1. Into Panels 6 7 and 8 insert 5 x Barrel Nuts **F**
- 2.Connect Bars 1 and 2 to Panels 6 7 and 8 with 4 x Screw E using Allen Key G provided
- 3. Connect Top Rail 5 using 1 x Screw



Assembly Instructions


Step 4

- 1. Into Panels 6 7 and 8 insert 5 x Barrel Nuts **6**
- 2. Locate bars 3 and 4 onto Panels 6 7 and 8
- 3.Connect Bars 3 and 4 to Panels 6 7 and 8 with 4 x Screw susing Allen Key G provided
- 4. Connect Top Rail 5 using 1 x Screw **C**

Step 5

1. Connect 4 x hooks \oplus to Uprights bars using 4 x Screw \bigcirc as shown.

Assembly Complete



If you need help or have damaged or missing parts, call the **Customer Helpline: 0345 640 0800**Argos LTD. 489-499 Avebury boulevard, Central Milton Keynes, MK9 2NW