



INSTRUCTION MANUAL



McGregor Dome Greenhouse

Model: 7189429 (MGNPGHD)

Important - Please read these instructions fully before starting assembly

These instructions contain important information that will help you get the best from your product, ensuring it is assembled correctly and safely. If you need help or have damaged or missing parts, call the Customer Helpline on **0345 640 2020**

**AFTER SALES SUPPORT
0345 640 2020**

Customer Helpline **0345 640 2020**

Contents

Package contents/parts 02

Assembly 03

Safety 07

Technical data 08

Produced in China for Argos Limited, London.

EC1N 2HT, UK. [Argos \(N.I.\) Ltd](#), Forestside Shopping

Centre, Upper Galwally, Belfast, BT8 6FX .UK.

argos.co.uk/help/contact-us

Package contents/parts

G		6
①		6
②		6
③		6
④		6
⑤		1
⑥		4
⑦		4
⑧		6
	 Cover	1

Assembly Instructions

Please read before assembly and keep for future reference.


INSTRUCTIONS

- Starting with the cover unzipped.
- Assemble as shown in figure.
- Secure to frame with ties attached to inside of cover.


IMPORTANT

- Please check the pack contains before assembly. And remember the codes/letters of different tubes.
- A full list of parts is given at previous page.
- The item should be sited in a sheltered spot away from prevailing winds.
- To avoid damage to the cover please unfold it carefully and allow it to rest until completely flexible.
- If cover fits tight, please make sure tubes are fully into connectors. If necessary, support connectors by wall or ground, then apply some gentle pressure on tubes.


1




2



3



4



Safety



Risk of injury!

Improper use or assembly of the Dome greenhouse may result in injury.

- Finding someone to assist may make the installation easier.
- Do not assemble the Dome greenhouse in strong wind or under bad weather.
- Do not leave children unattended nor allow them to play with the greenhouse. The Dome greenhouse is not a climbing frame or toy.
- Make sure children do not play with the plastic wrapper. They may get caught in it when playing and suffocate.
- Only set up the Dome greenhouse on a flat, level and stable surface. Otherwise, there is a risk of it falling over and injury.
- Be careful of where you place your fingers and hands when assembling the Dome greenhouse. You may accidentally pinch your fingers and/or hands.
- Only use the Dome greenhouse when it has been appropriately assembled.
- Evenly distribute the load on the Dome greenhouse so that it cannot overturn.
- Always remove all items from the Dome greenhouse before moving it.
- Do not stand, lean or jump on the Dome greenhouse. Do not use the Dome greenhouse as a climbing aid or steps.
- Do not rely on the Dome greenhouse as your shelter from extreme weather.
- Never store the Dome greenhouse in such a way that there is a risk of it falling over, or falling from an elevated position.

NOTICE!

Risk of damage!

Improper handling of the Dome greenhouse may result in damage to the Dome greenhouse.

- Do not position the Dome greenhouse in an area exposed to excessive wind.
- Make sure the Dome greenhouse is stable before use.
- In winter, regularly remove the accumulated snow on the roofs of the Dome greenhouse to avoid dangerous snow-loading.
- Never place the Dome greenhouse on or near heat sources such as ovens or heaters.
- Do not light a fire inside the Dome greenhouse.

- Do not use the Dome greenhouse if it is cracked, deformed or broken.
- Avoid spots where the Dome greenhouse may stand in water for long periods.
- Regularly check that all connections are secure.
- Do not exert any pressure on the Dome greenhouse. The Dome greenhouse may become imbalanced and tip over.
- Do not combine two or more Dome greenhouse together and use as one unit.

Cleaning

Improper handling of the Dome greenhouse may result in damage to the Dome greenhouse.

- Do not use any aggressive cleaners, brushes with metal or nylon bristles, or sharp or metallic cleaning utensils such as knives, hard scrapers and the like. They could damage the surfaces.
1. Remove all items from the Dome greenhouse.
 2. Wipe the Dome greenhouse clean with a damp cloth. Use a mild detergent if necessary for stubborn stain.
 3. Let all parts dry completely.

Storage

All parts must be completely dry before being stored.

- The cover can be removed and the main frame should be disassembled for storage.
- Always store the Dome greenhouse in a dry area and keep it out of direct sunlight.
- Store the Dome greenhouse so that it is not accessible to children.

Technical data

Model:	7189429 (MGNPGHD)
Weight:	Approx. 3.8 kg
Dimension (W×D×H):	Approx. W160 × D160 × H180 cm

