

ANDREW BARTON

LONDON



SALON PRO-DRY
Professional 2100W AC Dryer

Model 5568ABBU
andrew-barton.com

SAFETY CAUTIONS

- This appliance should only be used as described within this instruction booklet. Please retain for reference.

IMPORTANT CHILD SAFETY

WARNING! Polythene bags over a product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

WARNING! THIS APPLIANCE GETS HOT!

- **ALWAYS** keep out of reach of children (during and after use and while cooling)
- This appliance should not be used, cleaned or maintained by children.
- Always take extra care if used on children or near children
- Do not use on very young children.

IMPORTANT SAFETY INFORMATION

- **UK Only:** This appliance must not be used in the bathroom.
- **Outside the UK:** If using the appliance in a bathroom, unplug after use as the proximity of water can be dangerous even if the appliance is switched off. For additional protection the installation of a residual current device (RCD) with a rated residual operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.



- Do not use the appliance near water contained in basins, bathtubs or other vessels.
- Do not immerse the appliance in water or other liquids.
- Always inspect the appliance before use for noticeable signs of damage. Do not use if damaged, or if the appliance has been dropped.
- Do not use if the appliance or lead are damaged. In the event of damage, discontinue use immediately. Contact the Conair Customer Care Line (refer to “UK After Sales Service” section for further information). No repair must be attempted by the consumer.
- Do not look down the barrel of the dryer when the dryer is switched on.
- Do not leave the appliance unattended when switched on or plugged in.
- Take care that the air vents do not become blocked when the appliance is in use. Ensure the rear filter is clear of hair and other debris before use (refer to Cleaning & Maintenance section for further information).
- This appliance is equipped with a safety thermostat. In the event of overheating, the appliance will either stop automatically or run hot and cold intermittently. Should this happen, switch the appliance off, unplug and allow to cool for 10 minutes. Ensure the rear filter is clear of hair and other debris (refer to Cleaning & Maintenance section for further information). Plug the appliance into

the mains and switch on. If the appliance continues to overheat, discontinue use immediately, switch the appliance off and unplug. Contact the Conair Customer Care Line (refer to “UK After Sales Service” section for further information).

- Do not place the appliance on any surface whilst in operation.
- Take care to avoid the hot surfaces of the appliance coming into direct contact with the skin, in particular the eyes, ears, face and neck.
- Careful adult supervision is required when this appliance is used on or near children. Do not use on very young children.
- This appliance should not be used by adults whose reduced physical, sensory or mental capabilities, or whose lack of experience and knowledge, might cause a hazard, unless they have been correctly instructed to understand the safe use and hazards involved and are adequately supervised.
- Allow the appliance to cool before storing away.
- After use, do not coil the lead around the appliance as this may cause damage. Instead coil loosely by the side of the appliance.
- This product complies fully with all appropriate EU and UK Legislation and the Standards relevant to this type and class of appliance. We are an ISO9001:2015 certified company that continually evaluates our Quality Management System performance.

If you have any queries regarding product safety and compliance, please contact the Conair Customer Care Line (refer to “UK After Sales Service” section.)

"Great tools are the secret to gorgeous looking hair! So I've designed my own unique range for you to achieve everyday glamour and create salon beautiful hair."



FEATURES

- Powerful 2100W AC hairdryer
- Ionic conditioning for a frizz free high shine finish
- Tourmaline-ceramic technology for advanced drying results
- 3 Heat settings I / II / III
- 2 Speed settings O / I / II
- COLD shot button
- Slim salon concentrator nozzle
- Diffuser
- 3 year guarantee

Ionic Technology

Many aspects of modern living, including air conditioning, contact with man-made fibres and air pollution, even brushing and towel drying hair contributes to a build-up of static. As a result hair becomes dull, “fly-away” and difficult to style.

Ionic technology neutralises the static, smoothing hair and leaving it looking shiny, conditioned and manageable.

INSTRUCTIONS FOR USE

- Ensure the hair is towelled dry and combed through to remove tangles prior to styling.
- Plug the appliance into a suitable mains socket.
- Select the required heat and speed settings.

- **ALWAYS** ensure to keep hair away from the rear filter to prevent it being sucked into the fan as this may cause the dryer to overheat.
- Use the higher heat / higher speed settings (II/III) for initial drying and the low heat / low speed settings (I) to finish drying and for styling.
- To set styled hair with cold air, hold down the COLD button. Once released, the cold air stops immediately to enable professional precision control.
- For additional control when styling, attach the concentrator nozzle and using the low heat / low speed settings (I), direct the airflow along the surface of the hair to be dried.
- To create natural curls and volume, attach the diffuser and use the low heat / low speed settings (I).
- After use, switch off and unplug the appliance. Allow to cool before storing away.

STYLING TIPS

Add extra body and volume to the hair by directing the airflow towards the roots and use a brush to hold up each hair section while drying for maximum lift. For a smooth straight look, divide the hair into sections and with the concentrator nozzle attached, use a brush to hold the hair taut as you dry. To create a tousled look or enhance natural curls, attach the diffuser and squeeze your hair with your fingers as it dries.

CLEANING & MAINTENANCE

To keep your hairdryer in the best possible condition and maintain optimum performance, the rear filter should be cleaned on a regular basis.


- Ensure the appliance is switched off, unplugged and cool.
- To remove the filter, simply turn it gently then lift away from the dryer. Using a soft brush, clean any hair and debris from the rear mesh of the dryer and the rear filter itself.
- Replace the rear filter, making sure it clicks into place, before using the dryer again.

Care of your dryer

- Do not use the dryer at a stretch from the power point. Stretching the connection between the lead and the dryer can be dangerous.
- Always keep the rear of the dryer away from your hair during use to prevent hair ingress.
- Always unplug after use. Smooth out the lead to remove kinks and prevent damage.
- Do not wrap the lead around the dryer, instead coil it loosely by the side.
- Make sure the dryer is used on the correct voltage.

SAFE DISPOSAL



The  symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be handed to an appropriate collection point for the recycling of Electrical and Electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the recycling of this product, please contact your local council office or your household waste disposal service.

UK GUARANTEE

This appliance is guaranteed for consumer use for 3 years.

Please keep your receipt as proof of purchase to validate the guarantee. This guarantee covers defects under normal use from date of purchase and ceases to be valid in the event of alteration or repair by unauthorised persons. If the appliance does not perform satisfactorily due to defects in materials or manufacture, it will be repaired or replaced through the Conair UK After Sales Service. The Conair Group Ltd reserve the right to amend terms and specifications without prior notice.

This guarantee in no way affects your statutory rights.

UK AFTER SALES SERVICE

For further advice on using the appliance or should you need to return your product, please contact the Conair Customer Care Line on 03705 133191 (09:00 to 17:00 Monday to Friday) or email your enquiry to ukinfo@conair.com

The return address is:

Customer Care Centre
Conair Logistics
Unit 4 Revolution Park
Buckshaw Avenue
Buckshaw Village
Chorley
PR7 7DW

Please enclose your returns number, name and address details, together with a copy of proof of purchase and details of the fault.