


# High back sofa set - Chair

Assembly Instructions - Please keep for future reference

743/7377



## Dimensions

Width - 61cm

Depth - 64cm

Height - 89cm



**Important:** Do not fully tighten all screws until assembly is complete.

**Important – Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, call the

**Customer Helpline: Argos = 0345 6400800**

For further assistance please visit <http://www.argos-support.co.uk>

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW



# Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on pages 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product during assembly, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the chair or your floor.
- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.
- Maximum safe seated weight: 110kgs.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this chair.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.
- Make sure each screw matches the corresponding figure to ensure correct assembly.
- Do not fully tighten all screws until assembly is complete.



## Friendly Tips









- Do not fully tighten all screws until assembly is complete.
- Make sure the assemble will be easier with 2 people.

# Components - Parts & Fittings

If you have damaged or missing components, call the **Customer Helpline: Argos = 0345 6400800**

Please check you have all the parts & fittings listed below

*Note:* The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


<p><b>1</b></p>  <p>Left Armrest x 1</p>	<p><b>2</b></p>  <p>Right Armrest x 1</p>	<p><b>3</b></p>  <p>Backrest x 1</p>
<p><b>4</b></p>  <p>Seat x 1</p>	<p><b>5</b></p>  <p>Cushion x 1</p>	<p><b>A</b></p>  <p>M6X30mm Screw x 4</p>
<p><b>B</b></p>  <p>M6X35mm Screw x 6</p>	<p><b>D</b></p>  <p>Washer x 10</p>	<p><b>E</b></p>  <p>Screw caps x 10</p>

## Tools provided



**F** Allen key x 1


## Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions

## Step 1


Use long screws **B** and washers **D** to fix the armrest **1** and **2** to the backrest **3**.



**Important:**  
Do not fully tighten all screws until assembly is complete.

## Step 2

Use screws **A** **B** and washers **D** to fix the seat **4** to the armrest **1** **2** and backrest **3**.




Tighten all the screws and cover all the screws **A** and **B** with cap **E**.

# Assembly Instructions

## Step 3

Put the seat cushion **5** onto the chair.



**Assembly is complete**

If you need help or have damaged or missing parts, call the

**Customer Helpline: Argos = 0345 6400800**

For further assistance please visit <http://www.argos-support.co.uk>

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW