2 SEATER METAL SWING CHAIR

Assembly Instructions - Please keep for future reference | 7450859



Dimensions
Width - 145cm Depth - 112cm Height - 150cm

IMPORTANT-PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6403030
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West. Central Milton Keynes Bucks. MK9. 2NW

Issue 1 - 01/10/10

Safety and Care Advice

• Check you have all the components and tools listed on page 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Assemble the unit as close to its final position (in the same room) as possible.

• Parts of the assembly will be easier with 2 people.

• If using power tools,please follow the safety instructions supplied with the tools.

• This product is for domestic use.



• We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

• Warning:The unit weights approxomately 16 kgs.

Safety weight:220kgs per seat

Please lift with care.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

• Suggestion:When you do not use it ,find one suitable cover on it.




• Don`t fully tighten all screws until assembly is complete.

• Make sure each screw match the correspondingfigure to ensure correct assembly.

Components - Parts

If you have damaged or missing components, call the Customer Helpline: 0345 6403030






Please check you have all the parts listed below

1  Front Leg x 2	2  Rear Leg x 2	3  Upper Connect Tube x 1	4  Canopy U-shape Tube x 2
5  Canopy Tube x 2	6  Seat Cushion x 1	7  Armrest x 2	8  Canopy x 1
9 Hanging Tube x 4	10  Lower Connect Tube x 1	11 Side Connect Tube x 2	12  Seat x 1


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required. Bradawl,spanner and screwdriver are required but excluded.

A  M10x40 Plastic Switch x 2	B  M8x90 Bolts x 4	C  M8 Nuts & Washers x 4	D  M6x60 Bolts x 6
E  M6 Nuts & Washers x 14	F  M6x35 Bolts x 2	G  M6x45 Bolts x 4	H  M6x55 Bolts x 2
I  Spring hook x 2	J  Foot x 4	K  M8 Cap x 4	L  M6 Cap x 14
M  Plastic Sleeve x 8	N  Wrench x 1	O  Allen Key x 1	

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1


2 person required

A: Fix front leg[1],upper connect tube[3] and rear leg[2]together using bolts Ⓑ washers and nuts Ⓒ.

B: Fix the feet Ⓙ to the legs.

FULLY TIGHTEN ALL NUTS.

Then use nut covers Ⓚ to cover the nuts
(See fig .1)




Step 2

Fix side connect tube[11] between front leg[1] and rear leg[2] using bolts Ⓖ, washers and nuts Ⓔ.

FULLY TIGHTEN ALL NUTS.

Then use nut covers Ⓛ to cover the nuts
(See fig .1)




Step 3

Fix lower connect tube[10] between two rear legs[2] using bolts Ⓓ,washers and nuts Ⓔ.

FULLY TIGHTEN ALL NUTS.

Then use nut covers Ⓛ to cover the nuts
(See fig .3)



If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6403030
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West. Central Milton Keynes Bucks. MK9. 2NW

Assembly Instructions

Step 4

A: Cap the both ends of the hanging tubes 9 by plastic sleeve Ⓜ.


B:Fix the armrest 7 and hanging tubes 9 to the seat 12 using bolts ⒹⒻⒽ, washers and nuts Ⓔ.

FULLY TIGHTEN ALL NUTS.

Then use nut covers Ⓛ to cover the nuts
(See fig .4)

⚠ Important: Before open the seat, please adjust the textiene to right position and differentiate the seat and back side.

fig.4




Step 5

A: Use spring hook Ⓘ to hang the seat, then put seat cushion 6 on the seat.

B: Use plastic switch Ⓐ to fix the canopy U shape tube 4 to the both sides of the upper connect tube.
(See fig .5)

C: Put the seat cushion 6 to the seat 12 and fixed by bendage.


fig.5



Step 6

Insert the canopy tube 5 to the canopy 8 then connect it to the canopy U shape tube 4.
(See fig .6)

fig.6



If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6403030
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West. Central Milton Keynes Bucks. MK9. 2NW