


OPTI 7FT X 5FT Metal Football Goal

Assembly & User Instructions - Please keep for future reference

750/8536

Components - Parts




A - Screw Set x 8




B - Net x 1




P - Ground Pegs x 4



1. Top & Bottom curve x 4




2. Middle Straight x 2




3. Top Post Upright x 2




4. Bottom Post Upright x 2




5. Bottom End L/H x 1




6. Bottom End R/H x 1



7. Top Back Curve x 2



8. Rear Connector x 2



9. Bottom Back Curve x 2

Assemble Instructions



WARNING
Choking Hazard
Not suitable for children under 3 years, as product contains small parts.




WARNING
A minimum of two people should be used to assemble the goal set.


To be assembled & dismantled by an adult.
To be used on a flat surface.
Check all buttons are firmly tight and the frame assembly is securely pegged to ground before use.
Do not leave outdoors in adverse weather conditions.
Do not climb or hang from cross bar.
Check regularly for wear and tear.
Discontinue use if any breakage is found.
Failure to do this may result in injury.
Keep away from fire.
Keep away from heat sources.

- 1 Open all packaging and organise all straight and curved poles into numbered groups. Each pole will have a number on it (1-9) matching the parts list above.


- 2 To connect the poles together, slide the smaller connecting end inside the corresponding pole end. Some poles will have a connecting button to lock poles together. Simply press this button down, while sliding it inside a connecting pole, as shown.
Note: If this joint feels tight to assemble a little washing up liquid on the small connecting end will help slide together.



- 3 Follow the numbered diagram below and assemble top curve (1) to middle straight (2) to complete top frame.




- 4 **IMPORTANT:** Attach the net at this point. As you build each part of the frame, you will need to thread the loops at the edge of the net over each part of the frame poles. The end result should be the net (B) hangs from the top bar and down to the back floor frame.




Important – Please read these instructions fully before assembly or using

These instructions contain important information which will help you get the best from your equipment and ensure safe and correct assembly, use and maintenance.
If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6402020


Assemble Instructions



5




Continue to build the frame using tubes 3 to 6 again remember to thread the net through the top and bottom post uprights (3 & 4) also the bottom curve and middle straight (1 & 2) at the rear on the floor. Ensure all button clips are seated and secure.



6



Pre-assemble the top and bottom back curves to the rear connecting tubes (7 & 8). Then insert this assembly from the front of the goal, which will push out the net to form the goal shape.

Secure the top back curve (7) to the top post upright (3) using the screw set (A) Bolt, washer and wingnut as shown. Repeat for opposite side.



7

Secure the bottom back curve (9) using the screw set (A) through the two holes in the bottom curve (1) and bottom end L/H (5). The repeat operation for the right hand side of the goal.



Argos Ltd
489 - 499 Avebury Boulevard
Central Milton Keynes
MK9 2NW

Made in China

