

2pk 3.5ft Prelit Potted Porch Trees

Assembly Instruction - Please keep for future reference

7560639



Dimensions

Width - **60 cm**

Depth - **60 cm**

Height - **106 cm**

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- **PRODUCT IS INTENDED FOR INDOOR AND OUTDOOR USE.**
- To replace batteries, loosen the locking screw to remove the cover. Insert 3 X AA batteries with correct polarity then replace the cover and secure the screw. Do not over-tighten.
- Never look directly into the LED light source.
- Do not operate this product in the packaging.
- Do not position where it will be exposed to extreme wet weather or submerged in water.
- The cable on this decoration can not be replaced; if the cable becomes damaged discard of this product.
- THIS IS NOT A TOY - children and pets must be supervised when near this decoration.
- Keep away from heat and sources of ignition.
- This product is intended for use as a Christmas decoration only and is not suitable for household room illumination. WARNING. Do not use the product other than for its intended use.
- Do not cover the product with cloth, paper or any other material not part of the product when in use. e.g. curtains, nets or bedding.
- This light set is constructed with non replaceable LED light, DO NOT attempt to replace any of the LED bulbs in the light set.
- Do not connect the light set to any other light set by cutting or joining the sets together.
- Do not secure the wiring with sharp hooks or nails. This can cut or damage the wire insulation.
- Do not hang ornaments or other objects from the cord, wire or light strings.
- Do not let LED rest on the supply cord or any other wire.
- To reduce risk of fire, do not deliberately reposition either LED holder contact.
- Ensure the product is stable, position on a firm and level surface.
- Positioned where it is not a tripping or entrapment hazard.
- To avoid the risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
- Please refer to the packing or product rating label for product class, specifications and rating.

Installation - Selecting a Location

- Decide on an appropriate location for your product, make sure that you have plenty of space, a level surface and a clean dry area for assembly and location. Always try to assemble the product as close as possible to the intended location.

Components

Please check you have all parts listed below

- 2 x trees
- 2 x plastic pots
- 2 x battery boxes

Assembly Instructions

- 1) Choose a location where the tree is to be displayed.
- 2) Take out the two trees and pots from the carton, place them on a flat surface.
- 3) The tree comes in one section. Insert the tree section into the pot, as **Fig. 1**.




Fig. 1

- 4) Finally shape the tree by arranging the tips on the branches to give the desired effect. Some tree styles have “side branches” attached to the main branch stem that require additional shaping as shown in **Fig. 2**. After shaping the tree, the finished look should be natural and full.



Fig. 2

- 5) Next, open the battery box following the below relevant steps. Insert 3 x 1.5V AA batteries with the correct polarity (+/-). Then, close the battery box following the below relevant steps, as **Fig. 3**.

Guide to opening the battery box:

Step-1 Open the clip

Step-2 Loosen the screw

Guide to closing the battery box:

Step-1 Tighten the screw

Step-2 Lock up the clip




Fig. 3

- 6) Timer: Set the timer so that the lights will come on automatically at the same time every day; 8 hours on/16 hours off.
- 7) Press the ON/OFF button to turn on the lights and check that all bulbs are lit.

Storage

Before storing the product, carefully remove the product from wherever it is placed to avoid undue strain or stress on the product conductors, connections and wires.

- Remove all decorations from the tree.
- Gather the branches upwards and secure them in place.
- Gently lift off the tree section out of the stand (pot).
- Remove the batteries from the battery compartment to avoid leakage and corrosion.
- Carefully place the tree in its box and tape it shut. **STORE THE PRODUCT IN A COOL AND DRY LOCATION PROTECTED FROM SUNLIGHT AND WHERE THE TEMPERATURE DOES NOT EXCEED 40°C.**

Trouble Shooting

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



Waste electrical products should not be disposed of with household waste.

Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

Made in China for Habitat, Argos Limited.
Sainsbury's Supermarkets Ltd, London,
EC1M 6HA, UK. Argos (N.I.) Ltd and
Sainsbury's (NI) Ltd. Forestside Shopping Centre,
Upper Galwally, Belfast, BT8 6FX, UK.

habitat.co.uk/help/contact-us