



OPTI TWIN FLEXI FOOTBALL GOAL

Assembly & User Instructions - Please keep for future reference


619/3124




A - Net x 2



D - Frame Tubes x 12




B - Velcro Strap x 2




E - Elbow Connector x 4




G - Pump x 1



C - Straight Connector x 8



F - Ground Peg x 6



H - Football x 1

Assemble Instructions




WARNING
Choking Hazard
Not suitable for children under 3 years, as product contains small parts.



WARNING
A minimum of two people should be used to assemble the goal set.


To be assembled & dismantled by an adult.
To be used on a flat surface.
Check all joints are firmly tight and the frame assembly is securely pegged to ground before use.
Do not leave outdoors in adverse weather conditions.
Do not climb or hang from cross bar.
Check regularly for wear and tear.
Discontinue use if any breakage is found.
Failure to do this may result in injury.
Keep away from fire.
Keep away from heat sources.



Join 3 frame tubes (D) together using 2 Straight Connectors (C). Do this twice so you have two long poles as shown.

Note: If the connector joints are tight, lubricate with washing-up liquid.


- 2** Slide a set of frame tubes (D & C) into each of the fabric edging of the net (A).




Important – Please read these instructions fully before assembly or using

These instructions contain important information which will help you get the best from your equipment and ensure safe and correct assembly, use and maintenance.
If you need help or have damaged or missing parts, call the Customer Helpline: 0345 6402020

Assemble Instructions




- 3** Insert the elbow connectors (E) into one frame tube, ensuring the strap holes face the same way and will be parallel to the floor after construction.




- 4** Place one end of the goal on a clean firm surface. Holding the top of the frame tubes, push downwards slowly. The frame tubes will bow, allowing you to push together the elbow connector at the top of the goals.


Turn the goal over and repeat.



- 5** To connect the velcro strap (B), loop through the holes on the elbow connector and attach to the connecting velcro section on the strap. Place the connected end on a clean, firm surface. Carefully bend the goal and repeat on other end of the goal.



- 6** Position the assembled goals in place and fix to the ground using the 3 ground pegs (F) per goal.



Note: To secure frame firmly to ground always anchor one peg at each anchor point as indicated.


Caution:

Check regularly that pegs are secure.

Loose pegs may cause injury.

Care should be taken when using a mallet as misuse may cause injury.

When assembled the goal is under tension. Extreme care must be taken when disassembling.



Argos Ltd
489 - 499 Avebury Boulevard
Central Milton Keynes
MK9 2NW

Made in China

